

# Barcode positioning system BE 901 PB (D) (H)



- \_ Safety instructions
- \_ Function description
- \_ Mounting and installation
- \_ Commissioning, Configuration
- \_ Diagnostics and troubleshooting
- \_ Technical data
- \_ Ordering information and accessories

**User Manual**

---

## TR-Electronic GmbH

D-78647 Trossingen  
Eglishalde 6  
Tel.: (0049) 07425/228-0  
Fax: (0049) 07425/228-33  
email: [info@tr-electronic.de](mailto:info@tr-electronic.de)  
[www.tr-electronic.com](http://www.tr-electronic.com)

---

### Copyright protection

This Manual, including the illustrations contained therein, is subject to copyright protection. Use of this Manual by third parties in contravention of copyright regulations is not permitted. Reproduction, translation as well as electronic and photographic archiving and modification require the written content of the manufacturer. Violations shall be subject to claims for damages.

---

### Subject to modifications

The right to make any changes in the interest of technical progress is reserved.

---

### Document information

Release date / Rev. date:	03/12/2024
Document / Rev. no.:	TR-E-BA-GB-0034 v03
File name:	TR-E-BA-GB-0034-03.docx
Author:	STB

---

### Font styles

*Italic* or **bold** font styles displays text, which is visible on the display or screen and software menu selections.

---

### Brand names

PROFIBUS-DP and the PROFIBUS logo are registered trademarks of PROFIBUS Nutzerorganisation e.V. (PNO) [PROFIBUS User Organization]  
SIMATIC is a registered trademark of SIEMENS corporation

---

# Contents

<b>Revision index .....</b>	<b>7</b>
<b>1 About this document.....</b>	<b>8</b>
1.1 Used symbols and signal words .....	8
<b>2 Safety .....</b>	<b>10</b>
2.1 Intended use .....	10
2.2 Foreseeable misuse .....	11
2.3 Competent persons .....	11
2.4 Exemption of liability .....	12
2.5 Laser warning notices.....	12
<b>3 Device description.....</b>	<b>13</b>
3.1 Device overview.....	13
3.1.1 General information .....	13
3.1.2 Performance characteristics .....	14
3.1.3 Accessories.....	14
3.1.4 Device model with heating.....	14
3.2 Connection technology .....	15
3.2.1 BE 901 MS PB connection hood with M12 connectors .....	15
3.2.2 BE 901 MK PB connection hood with spring-cage terminals .....	16
3.3 Display elements .....	18
3.3.1 LED indicators.....	18
3.3.2 Display indicators.....	19
3.4 Barcode tape.....	20
3.4.1 General information .....	20
3.4.2 Control barcodes.....	22
3.4.3 Marker labels .....	26
3.4.4 Twin tapes.....	27
<b>4 Functions .....</b>	<b>27</b>
4.1 Position measurement .....	28
4.2 Speed measurement .....	28
4.3 Timing .....	29
4.4 TR webConfig tool .....	29
4.5 Evaluation of the reading quality.....	29
4.6 Status query of position / speed measurement .....	30
4.7 Distance measurement to the barcode tape.....	31
<b>5 Applications .....</b>	<b>31</b>
5.1 High-bay storage device .....	32
5.2 Telpher line .....	33
5.3 Gantry cranes .....	34

<b>6 Mounting and installation .....</b>	<b>35</b>
6.1 Mounting barcode tape .....	35
6.1.1 Installation and application remarks .....	35
6.1.2 Cutting barcode tapes .....	37
6.1.3 Mounting of the BCB .....	38
6.2 Mounting barcode positioning system .....	42
6.2.1 Mounting instructions .....	43
6.2.2 Orientation of the BE 901 PB to the barcode tape .....	44
6.2.3 Mounting with the BE 901 FA-001 mounting device .....	45
6.2.4 Mounting with BE 90 FA-001 mounting device .....	45
6.2.5 Mounting with the BE 901 FA-002 mounting bracket .....	46
6.2.6 Mounting with BE 901 FA-003 mounting device .....	46
6.2.7 Mounting with M4 fastening screws .....	46
<b>7 Electrical connection .....</b>	<b>47</b>
7.1 External parameter memory in the connection hood .....	47
7.2 BE 901 MS PB connection hood with connectors .....	48
7.3 BE 901 MK PB connection hood with spring-cage terminals .....	49
7.4 Pin assignment .....	51
7.4.1 PWR / SW IN/OUT (Power and switching input/output) .....	51
7.4.2 HOST / BUS IN (Host/Bus input, PROFIBUS) .....	53
7.4.3 BUS OUT (bus output, PROFIBUS) .....	54
7.4.4 Service USB .....	55
7.5 PROFIBUS topology .....	56
7.6 Cable lengths and shielding .....	56
<b>8 Commissioning – Basic configuration .....</b>	<b>57</b>
8.1 Configuring the PROFIBUS interface .....	57
8.1.1 Communication profile .....	58
8.1.2 Bus-access processes .....	58
8.1.3 Device types .....	58
8.1.4 Automatic baud rate detection .....	59
8.2 Setting the PROFIBUS address .....	59
8.3 Starting the device .....	61
8.4 Configuring for the Siemens SIMATIC-S7 control .....	61
8.5 PROFIBUS project modules .....	63
8.5.1 Overview of the modules .....	64
8.5.2 Device parameter module – Permanently defined parameters .....	65
8.5.3 Module 1 – Position value .....	66
8.5.4 Module 2 – Static preset .....	67
8.5.5 Module 3 – Dynamic preset .....	68
8.5.6 Module 4 – Input/output IO 1 .....	68
8.5.7 Module 5 – Input/output IO 2 .....	71
8.5.8 Module 6 – Status and control .....	74
8.5.9 Module 7 – Position limit value range 1 .....	76
8.5.10 Module 8 – Position limit value range 2 .....	76
8.5.11 Module 9 – Error handling procedures .....	76

8.5.12 Module 10 – Speed .....	77
8.5.13 Module 11 – Static speed limit value 1 .....	78
8.5.14 Module 12 – Static speed limit value 2 .....	79
8.5.15 Module 13 – Static speed limit value 3 .....	79
8.5.16 Module 14 – Static speed limit value 4 .....	80
8.5.17 Module 15 – Dynamic speed limit value .....	81
8.5.18 Module 16 – Speed status .....	81
8.5.19 Module 20 – Free resolution .....	83
8.5.20 Module 21 – distance to the barcode tape (BCB).....	83
8.5.21 Module 22 – Control and marker barcodes .....	83
8.5.22 Module 23 – Tape value correction .....	84
8.5.23 Module 24 – Reading quality .....	85
8.5.24 Module 25 – Device status .....	85
8.5.25 Module 26 – Extended status .....	86
8.5.26 Module 28 - 16-bit position value .....	86
<b>9 Commissioning – webConfig tool .....</b>	<b>87</b>
9.1 Installing software .....	87
9.1.1 System requirements .....	88
9.1.2 Install USB driver .....	88
9.2 Start webConfig tool .....	89
9.3 Short description of the webConfig tool .....	90
9.3.1 Overview .....	90
9.3.2 <i>PROCESS</i> function .....	91
9.3.3 <i>ALIGNMENT</i> function .....	92
9.3.4 <i>CONFIGURATION</i> function .....	92
9.3.5 <i>DIAGNOSTICS</i> function.....	96
9.3.6 <i>MAINTENANCE</i> function .....	96
9.4 The role concept of the webConfig users .....	97
9.4.1 Roles .....	97
9.4.1.1 The role “Observer” .....	97
9.4.1.2 The role “Operator” .....	98
9.4.1.3 The role “Maintenance” .....	98
9.4.1.4 The role “Planning Engineer” .....	98
<b>10 Diagnostics and troubleshooting .....</b>	<b>99</b>
10.1 What to do in case of failure? .....	99
10.1.1 Diagnostics with webConfig tool .....	99
10.2 Operating indicators of the LEDs.....	100
10.3 Error messages on the display .....	100
10.4 Checklist for causes of errors .....	101
<b>11 Care, maintenance and disposal .....</b>	<b>103</b>
11.1 Cleaning.....	103
11.2 Servicing .....	103
11.2.1 Firmware update .....	103
11.2.2 BCB repair with repair kit .....	103
11.3 Disposing .....	104

---

<b>12 Technical data.....</b>	<b>105</b>
12.1 General specifications .....	105
12.1.1 BE 901 PB without heating .....	107
12.1.2 BE 901 PB with heating .....	108
12.2 Barcode tape.....	108
12.3 Dimension drawings .....	110
12.4 : Accessories dimension drawings .....	112
12.5 Barcode tape dimension drawings .....	115
<b>13 Ordering information and accessories .....</b>	<b>116</b>
13.1 BE 901 PB type overview .....	116
13.2 Connection hoods .....	116
13.3 Terminating resistor .....	116
13.4 Other accessories .....	116
13.5 Mounting device.....	117
13.6 Barcode tapes.....	117
<b>14 EC Declaration of Conformity .....</b>	<b>119</b>
<b>15 Appendix .....</b>	<b>120</b>
15.1 Barcode sample.....	120
15.1.1 BCB G40 barcode tape with 40 mm grid .....	120
15.1.2 BCB G30 barcode tape with 30 mm grid .....	121

## Revision index

Revision	Date	Index
First release	10/05/2016	00
- General update - Preferred heights for barcode tape removed	05/30/2017	01
General update (LASER CLASS 1)	02/01/2021	02
Chapter 12 Table 12.6: Product Reliability added	03/12/2024	03

# 1 About this document

## 1.1 Used symbols and signal words

Table 1.1: Warning symbols and signal words







 <b>WARNING</b>	Signal word for serious injury Indicates hazards that could result in serious or fatal injury if you do not follow the measures for danger avoidance.
 <b>CAUTION</b>	Signal word for light injuries Indicates dangers that can cause slight injuries if the measures for danger avoidance are not followed.
<b>NOTICE</b>	Signal word for property damage Indicates dangers that can cause damage to property if you do not follow the measures for avoiding danger.
	Symbol for dangers from harmful laser radiation

Table 1.2: Other symbols

	Symbol for tips Texts with this symbol provide you with further information.
	Symbol for action steps Texts with this symbol instruct you to perform actions.
	Symbol for action results Texts with this symbol describe the result of the previous action.



**Table 1.3: Terms and abbreviations**

BCB	Barcode tape
BE 901	Barcode positioning system - Series 901
CFR	Code of Federal Regulations
DAP	Device Access Point
DCP	Discovery and Configuration Protocol
EMC	Electromagnetic compatibility
EN	European standard
FE	Functional earth
GSD	General Station Description
GSDML	Generic Station Description Markup Language
GUI	Graphical User Interface
IO or I/O	Input/Output
I&M	Information & Maintenance
IP	Internet Protocol
LED	Light Emitting Diode
MAC	Media Access Control
MVS	Type of control barcode
MV0	Type of control barcode
NEC	National Electric Code
OSI	Open Systems Interconnection model
PB	PROFIBUS DP - Interface
PELV	Protective Extra-Low Voltage
PNO	PROFIBUS Nutzerorganisation e.V. (PROFIBUS User Organization)
PROFIBUS	Manufacturer independent, open field bus standard
RT	Real Time
SNMP	Simple Network Management Protocol
PLC	Programmable Logic Control
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
USB	Universal Serial Bus
UL	Underwriters Laboratories
UV	Ultraviolet
XML	Extensible Markup Language

## 2 Safety

This sensor was developed, manufactured and tested in line with the applicable safety standards. It corresponds to the state of the art.

### 2.1 Intended use

The device is an optical measuring system which uses visible red laser light to determine its position relative to a permanently mounted barcode tape.

All accuracy details for the BE 901 PB measurement system refer to the position relative to the permanently mounted barcode tape.

---

#### **⚠ CAUTION**

##### ***Only use approved barcode tapes!***

*The barcode tapes approved and offered by TR-Electronic GmbH are an essential part of the measuring system. Barcode tapes from external sources are not allowed and the intended use is not given for this case.*

---

#### **Areas of application:**

The BE 901 PB is designed for positioning in the following areas of application:

- Telfer line
- Travel and lifting axes of high-bay storage devices
- Repositioning units
- Gantry crane bridges and their trolleys
- Elevators

---

#### **⚠ CAUTION**

##### ***Observe intended use!***

*The protection of operating personnel and the device is not guaranteed if the device is not used in accordance with its intended use.*

- 👉 *Only operate the device in accordance with its intended use.*
  - 👉 *TR-Electronic GmbH is not liable for damages resulting from improper use.*
  - 👉 *Please read this operating manual before using the device. Knowledge of the operating instructions is part of the intended use.*
- 

---

#### **NOTICE**

##### ***Comply with conditions and regulations!***

- 👉 *Observe the locally applicable statutory provisions and the regulations of the employers' liability insurance associations.*
-

## 2.2 Foreseeable misuse

Any use other than that defined under “Intended use” or which goes beyond that use is considered improper use.

In particular, use of the device is not permitted in the following cases:

- in rooms with explosive atmospheres
- for medicinal purposes
- as own safety component in accordance with the machinery directive



*Use as a security-related component within a security function is possible with a corresponding conception of the combination of component parts by the machinery manufacturer.*

---

### **NOTICE**

#### **No intervention or changes to the device!**

- ✚ *Do not make any interventions or changes to the device. Interventions and changes to the device are not permitted.*
  - ✚ *The use of a barcode tape not approved by TR-Electronic GmbH is to be equated with an intervention or a change to the device / measuring system.*
  - ✚ *The device must not be opened. It does not contain any parts to be adjusted or maintained by the user.*
  - ✚ *A repair may only be carried out by TR-Electronic GmbH.*
- 

## 2.3 Competent persons

Connection, mounting, commissioning and adjustment of the device must only be carried out by competent persons.

Prerequisites for competent persons:

- They have a suitable technical education.
- They are familiar with the rules and regulations for occupational safety and safety at work.
- They are familiar with the original operating instructions of the device.
- They have been instructed by the responsible person on the mounting and operation of the device.

#### **Certified electricians:**

Electrical work must be carried out by a certified electrician.

Due to their technical training, knowledge and experience as well as their familiarity with relevant standards and regulations, certified electricians are able to perform work on electrical systems and independently detect possible dangers.

In Germany, certified electricians must fulfill the requirements of accident-prevention regulations BGV A3 (e.g. electrician foreman). In other countries, there are respective regulations that must be observed.

### 2.4 Exemption of liability

TR-Electronic GmbH is not liable in the following cases:

- The device is not being used properly.
- Reasonably foreseeable misuse is not taken into account.
- Mounting and electrical connection are not properly performed.
- Changes (e.g., constructional) are made to the device.

### 2.5 Laser warning notices

---



#### **NOTICE**

#### **LASER RADIATION - LASER CLASS 1**

*The device meets the requirements of IEC/EN 60825-1:2014 for a Class 1 laser product and the requirements of U.S. 21 CFR 1040.10 with the deviations as per Laser Notice No. 56 dated May 8, 2019.*

- ↪ *Observe the applicable legal and local laser safety regulations.*
  - ↪ *Access and modifications to the device are not permitted. The device contains no parts that need to be adjusted or maintained by the user. Repairs may only be carried out by TR-Electronic GmbH.*
- 

#### **! CAUTION**

#### **Do not open the device!**

- ↪ *Opening the device can lead to radiation exposure.*
-

## 3 Device description

### 3.1 Device overview

#### 3.1.1 General information

The BE 901 PB barcode positioning system uses visible red laser light to determine its position and its speed value relative to a barcode tape that is affixed along the travel path. This takes place in the following steps:


- Read a code on the barcode tape (see Figure 3.1)
- Determine the position of the read code in the scanning beam
- Calculate the position to within less than a millimeter using the code information and the code position relative to the device's center.

The position and speed values are then output to the controller via the host interface.

The BE 901 PB consists of device housing and interface connection hood for the connection to the control. The BE 901 PB can optionally be delivered with display and optics heating.

The following connection hoods are available for the connection of the PROFIBUS interface:

- BE 901 MS PB connection hood with M12 connectors
- BE 901 MK PB connection hood with spring-cage terminals



- 1: Barcode tape
- 2: Connection hood
- 3: Device housing
- 4: Middle of the scanning beam (device middle, output position value)

**Figure 3.1: Device construction, device arrangement and beam exit**

### 3.1.2 Performance characteristics

The most important performance characteristics of the barcode positioning system:

- Positioning with submillimeter accuracy from 0 to 10,000 m
- For the control at high traverse rates of up to 10 m/s
- Simultaneous position and speed measurement
- Working range: 50 to 170 mm; enables flexible mounting positions
- Interfaces: PROFINET fieldbus, PROFIBUS fieldbus, SSI
- Binary inputs and outputs for control and process monitoring
- Configuration via webConfig tool or fieldbus
- Diagnostics via webConfig tool or optional display
- Optional model with display
- Optional model with heating for use to -35 °C

### 3.1.3 Accessories

Special accessories are available for the barcode positioning system. The accessories are optimally matched to the BE 901 PB:

- Highly flexible, scratch-, smudge- and UV-resistant barcode tape
- Mounting devices for precise mounting with one screw
- Modular connection technology via connection hoods with M12 connectors or spring-cage terminals

### 3.1.4 Device model with heating

The barcode positioning system is optionally available as a model with integrated heating. In this case, heating is permanently installed ex works.

---

#### **NOTICE**

#### **No self-installation of the heating!**

🔗 *Self-installation of the heating on-site by the user is not possible.*

---

The heating consists of two parts:

- Front cover heater
- Housing heater

Features of the integrated heating:

- Extends the application range of the BE 901 PB to -35 °C
  - Supply voltage 18 ... 30 VDC
  - BE 901 PB enabling through an internal temperature switch (startup delay of about 30 min for 24 VDC and minimum ambient temperature of -35 °C)
  - Required conductor cross-section for the power supply: At least 0.75 mm<sup>2</sup>
- 

#### **NOTICE**

#### **Do not use ready-made cables!**

🔗 *It is not possible to use ready-made cables. The current consumption of the BE 901 PB is too high for the ready-made cables.*

---

## Function:

When the supply voltage is applied to the BE 901 PB, a temperature switch initially only supplies the heating with current (front cover heater and housing heater). During the heating phase (around 30 min), when the inside temperature rises above 15 °C, the temperature switch connects the BE 901 PB to the supply voltage. This is followed by the self-test and the changeover to read operation. The PWR LED lights up, showing overall readiness for operation.

When the inside temperature reaches approx. 18 °C, another temperature switch turns the housing heater off and, if necessary, back on again (if the inside temperature drops below 15 °C). This does not interrupt the read operation.

The front cover heater remains activated until an inside temperature of 25 °C is reached. At temperatures above this, the front cover heater switches off and, with a switching hysteresis of 3 °C, back on again at an inside temperature below 22 °C.

## 3.2 Connection technology

For the electrical connection of the BE 901 PB, the following connection variants are available:

- BE 901 MS PB connection hood with M12 connectors
- BE 901 MK PB connection hood with spring-cage terminals

The voltage supply (18 ... 30 VDC) is connected acc. to the connection type selected. Two freely programmable switching inputs/switching outputs for individual adaptation to the respective application are also available here.


### 3.2.1 BE 901 MS PB connection hood with M12 connectors

The BE 901 MS PB connection hood features three M12 connector plugs and a Mini-B type USB socket as a service interface for configuration and diagnostics of the BE 901 PB.



*In the BE 901 MS PB there are the address selection switches to set the PROFIBUS address and the integrated parameter memory for easy replacement of the BE 901 PB.*

*In the BE 901 MS PB both the settings and the PROFIBUS address are stored and automatically transferred to the BE 901 PB each time the device is started.*



- 1: PWR / SW IN/OUT: M12 plug (A-coded)
- 2: SERVICE: Mini-B USB socket (behind protective cap)
- 3: HOST / BUS IN: M12 plug (B-coded), PROFIBUS 0
- 4: BUS OUT: M12 socket (B-coded), PROFIBUS 1

Figure 3.2: BE 901 MS PB connection hood, connections

## NOTICE

### Shielding connection

✎ The shielding connection is done via the M12 connector housing.

### 3.2.2 BE 901 MK PB connection hood with spring-cage terminals

The BE 901 MK PB connection hood makes it possible to connect the BE 901 PB directly and without additional connectors.


- The BE 901 MK PB features three cable bushings in which the shielding connection for the interface cable is also located.
- A Mini-B type USB socket is used for service purposes and for configuration and diagnostic of the BE 901 PB.



*In the BE 901 MK PB there are the address selection switches to set the PROFIBUS address and the integrated parameter memory for easy replacement of the BE 901 PB.*

*In the BE 901 MK PB both the settings and the PROFIBUS address are stored and automatically transferred to the BE 901 PB each time the device is started.*

---



- 1: 3x cable bushing, M16 x 1.5  
2: SERVICE: Mini-B USB socket  
(behind protective cap)

**Figure 3.3: BE 901 MK PB connection hood, connections**



### Cable fabrication and shielding connection:

- ✎ Remove approx. 78 mm of the connection cable sheathing.  
15 mm of sheath of the shielded line must be freely accessible.
- ✎ Lead the individual wires into the terminals according to the diagram.


#### NOTICE

#### **Do not use wire-end sleeves!**

- ✎ When fabricating cables, we recommend against using wire-end sleeves.



*The shield is automatically contacted when the cable is lead into the metal screw fitting and fastened when the cord grip is closed.*



- 1: Diameter of contact area, cable: 6 ... 9.5 mm
- 2: Diameter of contact area, shield: 5 ... 9.5 mm

**Figure 3.4: Cable fabrication for connection hoods with spring-cage terminals**

### 3.3 Display elements

The BE 901 PB is available optionally with display, two control buttons and LEDs or with only two LEDs as indicators on the device housing.

#### 3.3.1 LED indicators

The device housing features the following multicolor LED indicators as primary display element:

- PWR
- BUS




Figure 3.5: Indicators on the device housing

Table 3.1: Meaning of the LED indicators on the device housing

LED	Color, state	Description
LED 1 PWR	Off	Device is switched off - No supply voltage
	Green, flashing	Device is being initialized - Supply voltage connected - Initialization running - No measurement value output
	Green, continuous light	Device in operation - Initialization finished - Measurement value output
	Red, flashing	Warning set - No measurement (e.g. no barcode tape)
	Red, continuous light	Device error - Device function is limited - Details via event log (see chapter 10.1.1 "Diagnostics with webConfig tool")
	Orange, continuous light	Service active - No data on the host interface - Configuration via USB service interface
LED 2 BUS	Off	No supply voltage
	Green, flashing	- Establishing communication to the master - Device waiting for communication to be re-established - No cyclical data exchange
	Green, continuous light	- Communication with master established - Cyclical data exchange active
	Red, flashing	- Parameterization or configuration failed - Communication error detected (DP Error) - No cyclical data exchange

### 3.3.2 Display indicators

The optional display of the BE 901 PB is only used as a display element. The display has the following features:

- Monochromatic with white background lighting
- Double line, 128 x 32 pixels
- Display language: English

Two control buttons can be used to control which values appear in the display. The background lighting is activated by pressing any control button and is automatically deactivated after ten minutes have passed.

The display shows the content on two lines:

- The upper display line shows the selected function as an English term.
- The lower display line shows the data of the selected function.




Figure 3.6: Display on the device housing

#### Display functions:

The following functions can be displayed and activated in the display:

- Position value
  - *Position Value*
  - Position value in mm displayed with "." as decimal separator character (e.g., + 34598.7 mm)
- Reading quality
  - *Quality*
  - 0 ... 100 %
- Device status
  - *BE901 Info*
  - *System OK / Warning / Error*
- I/O status
 

(Status of the inputs/outputs)

  - *I/O status*
  - *IO1 In: 0 / IO2 Out: 0*
  - In/Out depending on configuration, 0/1 for state of the I/O
- Device address for host communication
  - *BE901 Address*
  - Decimal value of the PROFIBUS address, e.g. 126
- Version information
 

Software and hardware version of the device

  - *Version*
  - *SW: V1.3.0 HW:1*



### NOTICE

#### **Laser activation by selecting Quality!**






☞ If position measurement is stopped, the laser is activated by selecting Quality.

---

The display is controlled via the control buttons:

-  – **Enter:** activate or deactivate the display shift function
-  – **Down:** scroll through functions (downwards)

Example: Representation of the I/O status on the display

1. Press button : Display flashes
2. Press button : Display changes from position value (*Position Value*) to reading quality (*Quality*)
3. Press button : Display changes from reading quality (*Quality*) to device status (*BE901 Info*)
4. Press button : Display changes from device status (*BE901 Info*) to I/O status
5. Press button : I/O status displayed, display stops flashing

#### **Display during device startup:**

During device startup, a startup display first appears which is briefly followed by the display with the version information.

The standard display after starting up the BE 901 PB is *Position Value*.

## 3.4 Barcode tape

### 3.4.1 General information

The barcode tape (BCB) is available in different variants:

- Barcode tape BCB G40 with 40 mm grid  
Code128 with character set C, increasing in increments of 4 (e.g., 000004, 000008, ... )
- Barcode tape BCB G30 with 30 mm grid  
Code128 with character set C, increasing in increments of 3 (e.g. 000003, 000006, ... )

A barcode tape consists of a sequence of individual position labels in one of the two grids. Defined cut marks are provided for cutting the BCB.

The barcode tape is delivered on a roll. A roll contains up to 300 m of BCB, with the wrapping direction from the outside to the inside (smallest number on the outside). If more than 300 m of BCB is ordered, the total length is divided into rolls of 300 m.

Barcode standard tapes in fixed length gradations as well as special tapes with individual tape start value, tape end value, individual length and height can be ordered from TR-Electronic GmbH (see chapter 13.6 "Barcode tapes").

### NOTICE

#### **Only one BCB type per system!**

☞ Use either only BCB G30 with 30 mm grid or only BCB G40 with 40 mm grid in a system.

If different grids are used in a system, the BE 901 PB cannot ensure accurate positioning.

---

## NOTICE


### Configure the BE 901 PB for the used BCB type!

- ✎ The used BCB type must be set in the BE901 configuration with the Tape selection parameter; see chapter 8.5.2 "Device parameter module – Permanently defined parameters".
- ✎ On delivery, the BE 901 PB is set for BCB G40 with a 40 mm grid.  
If the BCB G30 with a 30 mm grid is used, the Tape selection must be adjusted in the BE901 configuration.
- ✎ If the used BCB type does not correspond to the Tape selection configured in the BE 901 PB, exact position determination cannot be performed by the BE 901 PB.



Standard barcode tapes are available in different length gradations in the heights **47 mm** and **25 mm**.


### Barcode tape BCB G40 with 40 mm grid:



- 1: Position label with position value
- 2: Cut mark

Figure 3.7: Barcode tape BCB G40 with 40 mm grid

### Barcode tape BCB G30 with 30 mm grid



- 1: Position label with position value
- 2: Cut mark

Figure 3.8: Barcode tape BCB G30 with 30 mm grid


### 3.4.2 Control barcodes

With the aid of control barcodes, which are stuck over the barcode tape at the appropriate points, functions can be activated or deactivated in the BE 901 PB, e.g. switching of different position values at switches. Code type Code128 with character set B is used for the control bar codes.

#### **MVS label**

The *MVS* label is a control bar code for the direction-independent switching of the position values from one bar code tape to another in the middle of the control bar code label.

If, upon reaching the changeover position in the middle of the *MVS* label, the BE 901 PB does not detect the new BE 901 PB section in the scanning beam, the position value of the first BCB section is still output after the middle of the *MVS* label for half of the label width.




- 1: Control barcode
- 2: Deactivation of the position detection at the end of the control barcode

Figure 3.9: Arrangement of the MVS control barcode

### MV0 label

The *MV0* label is a control bar code for the direction-independent switching of the position values from one bar code tape to another in the middle of the control bar code label.

If, upon reaching the changeover position in the middle of the *MV0* label, the BE 901 PB does not detect the new BE 901 PB section in the scanning beam, no position is output from the middle of the *MV0* label.



- 1: Control barcode
- 2: Deactivation of the position detection from the middle of the control barcode

Figure 3.10: Arrangement of the *MV0* control barcode

### Arrangement of the control barcodes:

The control barcode is arranged to replace a position barcode or to connect two barcode tapes with different value ranges.

The control barcode *MVS* or *MV0* need not be immediately followed by a position label. For an uninterrupted determination of measured values, there may be a gap between the control barcode and the following position label of less than or equal to a label width (40 mm).

### NOTICE

#### Distance between two control barcodes!

✎ Make certain that there is only one control barcode (or marker label) in the scanning beam at a time.

The minimum distance between two control barcodes is determined by the distance between the BE 901 PB and barcode tape and the resulting length of the scanning beam.

The control barcodes are simply affixed over the existing barcode tape.

A control barcode should cover an entire position barcode and must have the correct grid dimension:

- 30 mm with BCB G30 barcode tapes
- 40 mm with BCB G40 barcode tapes



*Keep the gap between the BCBs that are switched between as small as possible.*

---



**Figure 3.11: Correct positioning of the control barcode**

---

### **NOTICE**

#### **Gaps in barcode tape!**

- ↪ Avoid polished and high-gloss surfaces.
  - ↪ Keep the gaps between the two barcode tapes and the control barcode as small as possible.
- 

### **Measurement value switching between two barcode tapes with different value ranges:**

The MVS or MV0 control barcode is used to switch between two barcode tapes.



## NOTICE

### 1 m difference of the barcode position values for correct measured value switching!

➤ If the BCB value ranges are different, make sure that the position value has a value distance of at least 1 m between the leading position barcode (before the control barcode) and the following position barcode (after the control barcode).

If the minimum distance between the barcode values is not maintained, the position determination may be disturbed.

➤ Example (BCB in 40 mm grid): If the last position barcode on the BCB is 75120 before the control barcode, the subsequent position barcode on the BCB after the control barcode must be at least 75220.

- The end of the preceding barcode tape and the start of the subsequent barcode tape can end and begin, respectively, with completely different position barcodes.
- BCB changeover by means of a control barcode always occurs at the same position, i.e., it serves to change from the preceding tape to the subsequent tape and vice versa.
- If the center of the BE 901 PB reaches the transition point of the control barcode, the device switches to the second BCB, provided the next position label is in the BE 901 PB's scanning beam (see Figure 3.12). The output position value is thereby always uniquely assigned to one BCB.

This means that the output position value is always clearly assigned to a BCB.




If the BE 901 PB does not detect the new BCB section upon reaching the changeover position, the position value output is dependent on the used control barcode.

MVS control barcode: The position value of the first BCB is output beyond the middle of the MVS label for half of the label width.

MV0 control barcode: No position values are output after the middle of the MV0 label.

- When the control label is passed, the new BCB value is output relative to the middle of the device or label.



- 1: Scanning beam
- 2: Middle of the control barcode
- 3: Middle of the BE 901 PB
- 4: Direction of movement

Figure 3.12: Changeover position with MVS control barcode for BCB changeover

### 3.4.3 Marker labels

Marker labels, which are affixed at the appropriate locations on top of the barcode tape, can be used to trigger various functions in the superior control. The BE 901 PB detects the defined marker labels in the scanning beam, decodes them, and makes them available to the control.

#### **NOTICE**

##### ***Distance between two marker labels!***

☞ *Make certain that there is only one marker label (or control barcode) in the scanning beam at a time.*

*The minimum distance between two marker labels is determined by the distance between the BE 901 PB and barcode tape and the resulting length of the scanning beam.*

#### **Definition of the marker label:**

The following combinations of letters and numbers may be used as marker labels:

- AA1
- BB1
- CC1
- DD1
- EE1
- FF1
- GG1


Marker labels are designed as follows:

- Color red
- height 47 mm
- with grid dimension 40 mm (BCB G40)
- with grid dimension 30 mm (BCB G30)
- Code 128 B

Marker labels are single labels and are delivered in a packaging unit of 10 pieces.

#### **Arrangement when using the marker label with positioning:**

The marker label must be attached to the barcode tape aligned with the grid of the actual coding. A position code should be visible before and after the marker label.



1: Marker label

**Figure 3.13: System arrangement of marker labels**

#### **Arrangement when using the marker label without positioning:**

The marker label must be positioned within the BE 901 PB's detection range.

### 3.4.4 Twin tapes

Twin tapes are jointly manufactured barcode tapes with the same value range.


#### NOTICE

**A twin tape always consists of two barcode tapes!**

↳ When ordering a twin tape, two barcode tapes are always included with an order.

Twin tapes are used if positioning with two barcode tapes is necessary, e.g., with crane systems or elevators.

Because they are manufactured jointly, both tapes have the same length tolerance. As a result, differences in length and code position are minimal. By having the same code position on both tapes, improved synchronization can be achieved during positioning compared to barcode tapes that are manufactured separately.



- 1: Twin barcode tape 1
- 2: Twin barcode tape 2

Figure 3.14: Twin tape with double numbering



*Twin tapes are always delivered in pairs on two rolls.  
If twin tapes are replaced, both tapes are to be replaced.*

## 4 Functions

This chapter describes the functions of the BE 901 PB and the parameters for adaptation to the respective application conditions and requirements.

Main functions:

- Position measurement
- Speed measurement

The following parameters are relevant for the timing of the position and speed measurement:

- Measurement value preparation  
Configurable response time
- Measurement error tolerance  
Configurable time-based error suppression

### 4.1 Position measurement

The output value of the position measurement is calculated from the measurement and the settings for resolution, preset, offset, etc.

The most important individual parameters for the position measurement are:

Parameter	Description	Range/Values
Position resolution	The parameter specifies the resolution of the position value. It acts only on the host interface. The resolution has no effect on the set parameter values such as offset or preset.	0,001 mm 0,01 mm 0,1 mm 1 mm 10 mm or free resolution
Unit	The parameter specifies the measurement unit of the measured position and speed. The selection of the measurement unit affects all parameters with measurement units.	Metric (mm) or Inch (1/100 in)
Offset	The offset is used to correct the position value by a fixed amount. If the offset is activated, the offset is added to the position value. This yields a new output value: Output value = position value + offset	1 mm or inch/100
Preset	Like the offset, the preset is used to correct the position value. With preset, a preset value is specified. The value is accepted during a corresponding event (switching input or fieldbus). If the preset is activated, this has priority over the offset.	1 mm or inch/100

### 4.2 Speed measurement

The current speed is ascertained and output on the basis of the respective position values. The most important individual parameters for the speed measurement are:

Parameter	Description	Range/Values
Speed resolution	The parameter defines the resolution of the speed value. It affects only the fieldbus output.	1 mm/s 10 mm/s 100 mm/s 1000 mm/s or free resolution
Averaging	The parameter specifies the averaging time of the calculated speed values in steps.	Steps: 2, 4, 8, 16, 32 ms

### 4.3 Timing

The BE 901 PB operates with a scanning rate of 1000 scans per second. A measurement value is ascertained every 1 ms.

The following parameters are relevant for the timing of the position and speed measurement:

Parameter	Description	Range/Values
Integration depth	The integration depth affects the measurement of position and speed. The <i>integration depth</i> parameter specifies the number of sequential measurements that the BE 901 PB uses for position determination. The integration results in smoothing of the output measurement value. An <i>integration depth</i> of 8 (position determination with 8 measurement values) results in a response time of 8 ms.	Factory setting: 8
Error delay time	Errors that occur are suppressed for the configured time. If no valid position or speed value can be ascertained in the configured <i>error delay time</i> , the last valid value is always output. If the error persists after the <i>error delay time</i> elapses, the value of the <i>Position / Speed value in case of error</i> parameter is then output (standard).	Factory setting: 50 ms

### 4.4 TR webConfig tool

The webConfig configuration tool offers a graphical user interface for the display of process data, configuration and diagnostics of the BE 901 PB via a PC; see chapter 9 "Commissioning – webConfig tool".

### 4.5 Evaluation of the reading quality

#### Output of the reading quality



*The BE 901 PB can diagnose the reading quality in the arrangement of the BE 901 PB to the barcode tape.*

- ↳ *The reading quality is displayed in % values.*
- ↳ *Despite optimum operating conditions, the reading quality may be slightly below 100%. This does not constitute a defect of the BE 901 PB or the barcode tape.*



*The factory preset warning threshold at a read quality < 60%, as well as a shutdown threshold at a read quality < 30%, corresponds to the experience of TR-Electronic GmbH in a typical application.*

*For applications that result in a deliberate interruption of the barcode tape (switches, expansion joints, vertical slopes/gradients), the preset thresholds can be adapted to the respective application.*

The reading quality depends on several factors:

- Operation of the BE 901 PB at the specified depth of field
- Number of barcodes in the transmission beam
- Number of barcodes in reading range
- contamination of the barcodes
- Travel speed of the BE 901 PB (number of barcode symbols within the time window)
- Incidence of ambient light on the barcode and on the optics (glass exit window) of the BE 901 PB

In particular, the reading quality is influenced in the following cases:

- Switches, expansion joints and other transition points where the barcode tape is not glued without interruption
- Vertical travel if at least three barcode symbols are not completely within the reading range of the sensor at any time.
- Vertical travel when the barcode tape has been cut at the marked cutting edges to adapt to the curve.



*If the reading quality is influenced by the factors listed above, the reading quality may drop to 0%.*

↳ *This does not mean that the BE 901 PB is defective, but that the read quality characteristics are reduced to 0% in the respective arrangement.*

↳ *If a position value is output at a read quality of 0%, it is correct and valid.*

---

The parameters for evaluating the reading quality are set in the interface-specific configuration; see chapter 8.5.23 "Module 24 – Reading quality".



*The read quality values are indicated via the optional display (Quality), the serial communication protocol and via the webConfig tool; see chapter 9.3.3 "ALIGNMENT function".*

---

The evaluation of the reading quality provides the following information, for example:

- The reading quality is constantly poor: contamination of the optics of the BE 901 PB
- The reading quality is always poor at certain position values: contamination of the BCB

## 4.6 Status query of position / speed measurement

Module 6 – Status and control (see chapter 8.5.8) and Module 16 – Speed status (see chapter 8.5.18) in the PROFIBUS configuration signal status information of the position/velocity measurement.

The following status information can be transmitted to the PROFIBUS master:

- Status information for position measurement: Input data 0.0 ... 1.7; see chapter 8.5.8 "Module 6 – Status and control"
- Status information for speed measurement: Input data 0.0 ... 1.5; see chapter 8.5.18 "Module 16 – Speed status"

## 4.7 Distance measurement to the barcode tape

Within the reading field, the BE 901 PB can output the current distance from the read head to the BCB. The distance from the position label closest to the reference point is output (see chapter 8.5.20 "Module 21 – distance to the barcode tape (BCB)").

The distance measurement value is output via:

- the *ALIGNMENT* function (*Quality* menu) in the webConfig tool (see chapter 9.3.3); this function is only available in the Service operating mode.
- the host interface (input data)

## 5 Applications

Wherever systems are moved automatically, it is necessary to uniquely determine their respective positions. In addition to mechanical measuring sensors, optical methods are particularly well suited for position determination as they can be used to determine position without mechanical wear and slippage.

Compared to common optical measurement techniques, the barcode positioning system (BE 901 PB) is able to measure a position with absolute sub-millimeter accuracy, i.e. independent of reference points. As a result, it is able to provide a unique position value at any time. With the highly flexible and hard-wearing Bar Code Tape (BCB), the system can even be used without problem in systems with curves or guide tolerances. And this at lengths of up to 10,000 meters.

The product family of TR-Electronic GmbH barcode positioning systems convinces with a variety of advantages:

- The laser simultaneously scans three barcodes and, as a result, is able to determine the position with sub-millimeter accuracy. The wide reading field makes accurate position determination possible even in the event of minor damage to the tape.
- With the systems' flexible depth of field, it is also possible to bridge over mechanical deviations.
- Due to the large reading distance combined with the great depth of field, a large opening angle and a very compact construction, the device is ideally suited for the conveyor and storage technology market.
- The BE 901 PB devices are capable of simultaneously measuring position and speed and are thus also suitable for control tasks in your automation applications.
- Using a mounting device, the BE 901 PB can be mounted with millimeter accuracy with just one screw. If mounted using a mounting device, a new device is automatically aligned correctly should it be necessary to exchange a device.
- Due to the unique coding of the position value on the barcode tape, the system can continue to operate without any problems even after a short-term voltage drop without having to resort to a reference point, for example.
- The barcode tape is very robust, highly flexible and, thanks to the self-adhesive back, can be easily integrated into your overall mechanical system. It can be fit optimally to both vertical as well as horizontal curved paths and thereby reliably facilitates trouble-free and reproducible measurement at any point in your system with sub-millimeter accuracy.

Typical applications for the BE 901 PB include:

- High-bay storage device (see chapter 5.1)
- Telfer line (see chapter 5.2)
- Gantry cranes (see chapter 5.3)



### 5.1 High-bay storage device




Figure 5.1: High-bay storage device

- ↪ Simultaneous position and speed measurement for regulation tasks
- ↪ Precise positioning with a reproducibility of  $\pm 0.15$  mm
- ↪ Control at high traverse rates of up to 10 m/s



## 5.2 Telpher line




Figure 5.2: Telpher line

- ↪ Positioning from 0 to 10,000 meters
- ↪ The working range from 50 - 170 mm allows for flexible mounting positions and reliable position detection at varying distances
- ↪ Control codes for changing to different position values at switches

### 5.3 Gantry cranes




Figure 5.3: Gantry cranes

- ↗ Scratch- and smudge-proof, UV-resistant barcode tapes
- ↗ Synchronous positioning with twin tapes on both rails
- ↗ Mounting device for fast, precise mounting with one screw

## 6 Mounting and installation

### 6.1 Mounting barcode tape

#### 6.1.1 Installation and application remarks

---

##### **NOTICE**

##### **BCB mounting**

- ↪ When processing BCBs, observe the specified processing temperatures.

*When processing BCBs in cold storage facilities, the BCB must be affixed before cooling the storage facility.*

*However, if it should be necessary to affix the BCB at temperatures outside of the specified processing temperature, assure that the bonding surface as well as the BCB is at the processing temperature.*

- ↪ Avoid dirt deposits on the BCB.

*If possible, affix the BCB vertically.*

*If possible, affix the BCB below an overhead covering.*

*The BCB must never be continuously cleaned by on-board cleaning devices such as brushes or sponges. Permanent on-board cleaning devices polish the BCB and give it a glossy finish. The reading quality deteriorates as a result.*

- ↪ After affixing the BCBs, make certain that there are no polished, high-gloss surfaces in the scanning beam (e.g., glossy metal at gaps between the individual BCBs), as the measurement quality of the BE 901 PB may be impaired.

*Affix the BCBs to a diffusely reflective support, e.g., a painted surface.*

- ↪ Avoid sources of extraneous light and reflections on the BCB.

*Ensure that neither strong sources of extraneous light nor reflections of the support on which the BCB is affixed occur in the vicinity of the BE 901 PB scanning beam.*

- ↪ Affix the BCB over expansion joints up to a width of several millimeters.

*The BCB must not be interrupted at this location.*

- ↪ Cover protruding screw heads with the BCB.

- ↪ Ensure that the BCB is affixed without tension.

*The BCB is a plastic tape that can be stretched by strong mechanical tension. Excessive mechanical stretching results in lengthening of the tape and distortion of the position values.*

---

### **NOTICE**

#### **BCB application**

↪ Make certain that the BCB is located in the scanning beam of the BE 901 PB over the entire traversing path. The BE 901 PB can determine the position on BCBs with arbitrary orientation.

↪ Barcode tapes with different value ranges may not directly follow one another.

*For different value ranges, a gap of at least 1 m between the position value of the last position barcode of the leading BCB and the position value of the first position barcode of the trailing BCB must be maintained (see chapter 3.4.2 "Control barcodes").*

↪ For MVS/MV0 control barcodes (see chapter 3.4.2), the minimum distance of 1 m between the last position barcode before the control barcode and the first position barcode after the control barcode must be maintained.

↪ For barcode tapes with different value ranges, both BCBs must correspond to the BCB type configured in the BE 901 PB (see chapter 3.4.1).

↪ Avoid position barcode labels with the value 00000.

*Measurements to the left of the center of a 00000 label produce negative position values that may not be displayed correctly.*

---


## 6.1.2 Cutting barcode tapes

### NOTICE

#### Avoid cutting BCB!

- ↳ If possible, avoid cutting barcode tapes.  
Optimum position value determination by the BE 901 PB is achieved with continuously affixed BCB.
- ↳ If there are mechanical gaps, first affix the BCB continuously. Then cut the BCB.

The BCB is cut at the indicated cut marks.



1: Cut mark

Figure 6.1: Cut mark on the barcode tape


If another BCB is to be affixed directly after the preceding BCB, the subsequent barcode value must differ from the preceding BCB by at least 1 m; see Figure 6.2.



- 1: Preceding barcode tape
- 2: Cut mark
- 3: Subsequent barcode tape, value range + 1 m

Figure 6.2: Cut barcode tape

If there is a gap without tape after the preceding BCB, it must be at least 300 mm wide before the subsequent BCB is affixed; see Figure 6.3. The first barcode value of the subsequent BCB must differ by at least 20 (200 mm) from the last barcode value of the preceding BCB.



- 1: Preceding barcode tape
- 2: Cut mark
- 3: Gap, at least 300 mm
- 4: Following barcode tape

Figure 6.3: Gap in cut barcode tape to avoid double positions

### **NOTICE**

#### **No glossy gaps in the cut barcode tape!**

- ✎ Ensure that there are matt, bright surfaces behind the gaps in the BCB. Polished, reflective, and high-gloss surfaces in the scanning beam may impair the measurement quality of the BE 901 PB

### 6.1.3 Mounting of the BCB

Mount the BCB as follows:

- ✎ Check the surface.  
It must be flat, free of grease and dust, and be dry.
- ✎ Define a reference edge (e.g., metal edge of the busbar).
- ✎ Remove the backing and affix the BCB along the reference edge tension free.
- ✎ Secure the bar code tape to the mounting surface by pressing down with the palm of your hand.  
When affixing, make certain that the BCB is free of folds and creases and that no air pockets form.

## NOTICE

### **When mounting, do not pull on the BCB!**

The BCB is a plastic tape that can be stretched by strong mechanical tension.

The stretching results in lengthening of the tape and distortion of the position values on the BCB.

While the BE 901 PB can still perform the position calculation in the event of distortions, the absolute measurement accuracy is no longer ensured in this case. If the values are taught using a teach-in process, stretching of the BCB is irrelevant.



If a barcode tape was damaged, e.g., by falling parts, you can download a repair kit for the BCB (see chapter 11.2.2 "BCB repair with repair kit").

Use the barcode tape created with the repair kit only temporarily as an emergency solution.


### **BCB mounting in horizontal curves:**

## NOTICE

### **Limited absolute measurement accuracy and reproducibility!**

BCB mounting in curves impairs the absolute accuracy of the BE 901 PB, since optical distortions mean that the distance between two barcodes is no longer exactly 40 mm or 30 mm.

For horizontal curves, maintain a minimum bending radius of 300 mm (see Figure 6.4).



**Figure 6.4: Mounting the barcode tape for use in horizontal curves**



### BCB mounting in vertical curves:

---

#### **NOTICE**

##### **Limited absolute measurement accuracy and reproducibility!**

- ↪ BCB mounting in curves decreases the absolute measurement accuracy of the BE 901 PB, since the distance between two barcodes is no longer exactly 40 mm or 30 mm.
  - ↪ In areas where the BCB is fanned out around curves, limitations of the reproducibility must be expected.
- 

- ↪ Only partially cut the BCB at the cut mark.
  - ↪ Affix the BCB along the curve like a fan (see Figure 6.5).
  - ↪ Ensure that the BCB is affixed without mechanical tension.
- 

#### **NOTICE**

##### **No glossy gaps in the barcode tape!**

- ↪ Ensure that there are matt, bright surfaces behind the gaps in the BCB. Polished, reflective, and high-gloss surfaces in the scanning beam may impair the measurement quality of the BE 901 PB
- 





Figure 6.5: Preparing the barcode tape for use in vertical curves



### Mounting twin tapes:

If two barcode tapes with the same value range are used for positioning, e.g., for crane systems or elevators, the use of twin tapes is recommended (see chapter 3.4.43.4.3 "Twin tapes").

Twin tapes are provided with duplicate numbering. As a result, it is not necessary to affix the BCBs "upside down" in order to have the same values at the same position (see Figure 6.6).



- 1: Twin barcode tape 1
- 2: Twin barcode tape 2

Figure 6.6: Mounting twin tapes

### NOTICE

#### **A twin tape always consists of two barcode tapes**

- ✚ When ordering twin tapes, two barcode tapes are always delivered with one order.
- ✚ The two TWIN barcode tapes have exactly the same length tolerances to each other.
- ✚ Make sure that the BCB is attached without tension.  
The BCB is a plastic tape that can be stretched by strong mechanical tension. Excessive mechanical stretching will lengthen the tape and distort the position values.

### Mounting two barcode tapes with the same value range:

For crane systems or elevators, two barcode tapes with the same value range are used for positioning.




*If two barcode tapes with the same value range and the same length tolerances are required, the use of twin tapes is recommended (see chapter 3.4.4 "Twin tapes").*

If a twin tape is not used: To have the same values at the same position, one barcode tape must be affixed with numbers upside down while the other is affixed normally (see Figure 6.7).



*If no TWIN barcode tapes are used, the two barcode tapes can deviate +/- 1 mm per meter from each other.*



- 1: BCB affixed upside down
- 2: BCB affixed normally

**Figure 6.7: Affixing two barcode tapes with the same value range**

## 6.2 Mounting barcode positioning system

The BE 901 PB can be mounted in the following ways:

- Mounting using a mounting device on the fastening grooves
  - BE 901 FA-001 (BE901 Befestigung): (Wall mounting
  - BE 90 FA-001: Mounting on a rod
- Mounting using a mounting device on the M4 mounting threads on the rear of the device
  - BE 901 FA-002 (BE901 Befestigungswinkel): Mounting on a mounting bracket
  - BE 901 FA-003 (BE901 Befestigung kompl.): Mounting on a rod
- Mounting using four M4 mounting threads on the rear of the device



*If the BE 901 FA-001 mounting device is used to mount the device, the new device is automatically aligned correctly should it be necessary to exchange a device.*

## 6.2.1 Mounting instructions

### NOTICE

#### Select the mounting location.

- ↪ Make certain that the required environmental conditions (humidity, temperature) are maintained.
- ↪ Make certain that the distance between BE 901 PB and barcode tape is sufficiently large. The scanning beam of the BE 901 PB should cover three or more barcodes. The distance between BE 901 PB and barcode tape must be in the working range of the reading field curve.
- ↪ Make certain that the exit window does not become soiled, e.g., by leaking liquids, abrasion from cardboard packaging or residues from packaging material.
- ↪ Mounting the BE 901 PB outdoors or with BE 901 PB with integrated heating:  
Mount the BE 901 PB in a way which provides maximum thermal isolation, e.g., using rubber bonded metal.  
Mount the BE 901 PB so that it is protected from airflow, e.g., in a protective housing.
- ↪ Mounting the BE 901 PB in a protective housing:  
When installing the BE 901 PB in a protective housing, ensure that the scanning beam can exit the protective housing without obstruction.
- ↪ Make certain that the scanning range determined from the scanning curve is adhered to at all locations where a position determination is to be made.
- ↪ Ensure that the scanning beam is always incident on the BCB when the system is moving. For the position calculation, the scanning beam of the BE 901 PB must be incident on the BCB without interruption.  
For the best functionality, the BE 901 PB must be guided parallel to the BCB. It is not permitted to move outside of the approved working range of the BE 901 PB (50 ... 170 mm) while the system is in motion.
- ↪ Make certain that there is only one control barcode (or marker label) in the scanning beam at a time. The minimum distance between two control barcodes is determined by the distance between the BE 901 PB and barcode tape and the resulting length of the scanning beam.

### NOTICE

#### For parallel mounting, maintain the minimum distance!

- ↪ Maintain the minimum distance of 300 mm if you mount two BE 901 PB next to or above one another.




Figure 6.8: Minimum distance for parallel mounting


### NOTICE

**Install the connection hood before mounting the BE 901 PB!**

- ↪ Screw the BE 901 MS PB or BE 901 MK PB connection hood to the device housing with two M4 screws.
- ↪ Tighten the screws on the connection hood with a tightening torque of 1.4 Nm.

### 6.2.2 Orientation of the BE 901 PB to the barcode tape

The beam of the BE 901 PB must be oriented at an incline of  $7^\circ$  to the barcode tape (see Figure 6.9). When positioning, make certain that the angle of radiation to the rear side of the housing is  $90^\circ$  and the reading distance to the barcode tape is maintained.




- 1: Reading distance
- 2: Reference point for the barcode position
- 3: Scanning beam

**Figure 6.9: Beam exit**

### 6.2.3 Mounting with the BE 901 FA-001 mounting device

Mounting the BE 901 PB with a BE 901 FA-001 mounting device is intended for wall mounting. For ordering information see chapter 13.5; for dimensioned drawing see Figure 12.7.



**Figure 6.10: Mounting the BE 901 PB with the BE 901 FA-001 mounting device**

- ✚ Mount the BE 901 FA-001 on the system side with M6 fastening screws (not included in delivery contents).
- ✚ Mount the BE 901 PB with the dovetail fastening grooves on the clamping jaws of the BE 901 FA-001 with limit stop at end.
- ✚ Secure the BE 901 PB with the M6 screw terminal.  
Maximum tightening torque for the M6 screw terminal: 8 Nm

### 6.2.4 Mounting with BE 90 FA-001 mounting device

Mounting of the BE 901 PB with a BE 90 FA-001 mounting device is intended for rod mounting. For ordering information see chapter 13.5; for dimensioned drawing see Figure 12.9.

- ✚ Mount the BE 90 FA-001 on the rod with the clamp profile (system-side).
- ✚ Mount the BE 901 PB with its fastening grooves on the clamping jaws of the BE 90 FA-001 with limit stop at end.
- ✚ Secure the BE 901 PB with the M6 screw terminal.  
Maximum tightening torque for the M6 screw terminal: 8 Nm

### 6.2.5 Mounting with the BE 901 FA-002 mounting bracket

Mounting of the BE 901 PB with a BE 901 FA-002 mounting bracket is intended for wall mounting. For ordering information see chapter 13.5; for dimensioned drawing see Figure 12.8.

- ✚ Mount the BE 901 FA-002 mounting bracket on the system side with M6 fastening screws (included in delivery contents).
- ✚ Mount the BE 901 PB on the mounting bracket with M4 fastening screws (included in delivery contents).

Maximum tightening torque of the M4 fastening screws: 2 Nm

### 6.2.6 Mounting with BE 901 FA-003 mounting device

Mounting of the BE 901 PB with a BE 901 FA-003 mounting device is intended for rod mounting. For ordering information see chapter 13.5; for dimensioned drawing see Figure 12.10.

- ✚ Mount the BE 901 FA-003 mounting device with the clamp profile on the rod (system-side).
- ✚ Mount the BE 901 PB on the mounting bracket of the BE 901 FA-003 with M4 fastening screws (included in delivery contents).

Maximum tightening torque of the M4 fastening screws: 2 Nm

### 6.2.7 Mounting with M4 fastening screws




Figure 6.11: Dimensioned drawing of rear of BE 901 PB

- ✚ Mount the BE 901 PB on the system with M4 fastening screws (not included in delivery contents).

Maximum tightening torque of the fastening screws: 2 Nm

## 7 Electrical connection

### ⚠ CAUTION

- ↪ Before connecting the device, be sure that the supply voltage agrees with the value printed on the name plate.
- ↪ Only allow competent persons to perform the electrical connection.
- ↪ Ensure that the functional earth (FE) is connected correctly.  
Fault-free operation is only guaranteed if the functional earth is connected properly.
- ↪ If faults cannot be rectified, take the device out of operation. Protect the device from accidentally being started.

### ⚠ CAUTION

#### **UL applications!**

For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).

### NOTICE

#### **Protective Extra Low Voltage (PELV)**

- ↪ The BE 901 PB is designed in accordance with protection class III for supply with PELV (protective extra-low voltage).

### NOTICE

#### **Connection hood and degree of protection IP 65**

- ↪ Before connecting, mount the connection hood on the BE 901 PB device housing.
- ↪ To ensure degree of protection IP 65 is fulfilled, the screws of the connection hood are tightened with a tightening torque of 1.4 Nm for connecting to the BE 901 PB.
- ↪ Degree of protection IP 65 is not fulfilled until connectors or cable bushings are screwed on and caps are installed.


### 7.1 External parameter memory in the connection hood

The BE 901 MS PB and BE 901 MK PB connection hoods store the PROFIBUS address and keep a copy of the current BE 901 PB parameter set ready.

- When replacing the BE 901 PB device on site, the PROFIBUS address does not have to be set again, it remains in the connection hood. The PROFIBUS is not interrupted when replacing a device. BUS IN and BUS OUT are interconnected in the BE 901 MS PB and ensure the operation of the PROFIBUS even in case of replacement.
- An address switch is located in the connection hood to set the PROFIBUS address of the BE 901 PB. If the BE 901 PB is the last station on the PROFIBUS line, the socket on the BE 901 MS PB must be provided with a termination plug (see chapter 13.3 “Terminating resistor”) or the bus termination on the BE 901 MK PB must be activated using the slide switch T.

### 7.2 BE 901 MS PB connection hood with connectors

The BE 901 MS PB connection hood features three M12 connector plugs and a Mini-B type USB socket as a service interface.



- 1: PWR / SW IN/OUT: M12 plug (A-coded)
- 2: SERVICE: Mini-B USB socket (behind protective cap)
- 3: HOST / BUS IN: M12 plug (B-coded), PROFIBUS 0
- 4: BUS OUT: M12 socket (B-coded), PROFIBUS 1

Figure 7.1: BE 901 MS PB connection hood, connections

#### NOTICE

##### **Shielding connection and functional earth connection!**

- ✎ The shielding connection is done via the M12 connector housing.
- ✎ Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly.  
All electrical disturbances (EMC couplings) are discharged via the functional earth connection.

#### NOTICE

##### **PROFIBUS default address!**

- ✎ PROFIBUS address 126 is set by default in the BE 901 MS PB.  
The integrated parameter memory for the simple replacement of the BE 901 PB is located in the BE 901 MS PB.

#### NOTICE

##### **Bus interruption and bus termination!**


- ✎ The PROFIBUS is looped through the BE 901 MS PB, i.e. the bus is not interrupted when the BE 901 PB is removed from the BE 901 MS PB.
- ✎ The bus is terminated at BUS OUT via an external mounted terminating (see chapter 13.3 "Terminating resistor").  
If the termination is activated, the downstream bus cable is disconnected.



- ✚ Connect connection PWR / SW IN/OUT to the supply voltage or the switching inputs/outputs connection cable.
- ✚ Connect the HOST / BUS IN connection to the BUS OUT connection of the upstream BE 901 PB with the interconnection cable.
- ✚ Connect the BUS OUT connection to the HOST / BUS IN connection of the downstream BE 901 PB with the interconnection cable.
- ✚ If the current BE 901 PB is the last PROFIBUS participant, connect a terminating resistor to connection BUS OUT.

### 7.3 BE 901 MK PB connection hood with spring-cage terminals

With the BE 901 MK PB connection hood, the BE 901 PB is connected directly and with no additional plug. The BE 901 MK PB features three cable bushings in which the shielding connection for the interface cable is also located. A Mini-B type USB socket is used for service purposes.



- 1: 3x cable bushing, M16 x 1.5
- 2: SERVICE: Mini-B USB socket (behind protective cap)

Figure 7.2: BE 901 MK PB connection hood, connections

#### NOTICE

##### **Cable fabrication!**

- ✚ It is recommended not to use wire-end sleeves.

#### NOTICE

##### **Functional earth connection!**

- ✚ Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly. All electrical disturbances (EMC couplings) are discharged via the functional earth connection.

### **NOTICE**

#### **PROFIBUS default address!**

- ↪ *PROFIBUS address 126 is set by default in the BE 901 MK PB.*
  - ↪ *The integrated parameter memory for the simple replacement of the BE 901 PB is located in the BE 901 MK PB.*
- 

### **NOTICE**

#### **Bus interruption and bus termination**

- ↪ *The PROFIBUS is looped through the BE 901 MK PB, i.e. the bus is not interrupted when the BE 901 PB is removed from the BE 901 MK PB.*
  - ↪ *The bus is terminated via slide switch T in the BE 901 MK PB (see Figure 7.3).*  
*If the termination is activated (slide switch T in the ON position), the downstream bus cable is disconnected.*
- 

- ↪ Connect the connection PWR / SW IN/OUT to the supply voltage or the switching inputs/outputs connection cable.
- ↪ Connect the HOST / BUS IN connection to the BUS OUT connection of the upstream BE 901 PB with the interconnection cable.
- ↪ Connect the BUS OUT connection to the HOST / BUS IN connection of the downstream BE 901 PB with the interconnection cable.
- ↪ If the current BE 901 PB is the last PROFIBUS participant, set slide switch T to ON (see Figure 7.3) to activate bus termination.

## 7.4 Pin assignment

### 7.4.1 PWR / SW IN/OUT (Power and switching input/output)

5-pin, M12 plug (A-coded) or terminal block for connecting to PWR / SW IN/OUT.




Figure 7.3: PWR / SW IN/OUT connection

Table 7.1: PWR / SW IN/OUT pin assignment

Pin/terminal	Designation	Assignment
1	VIN	+18 ... +30 VDC supply voltage
2	SWIO1	Sw. input/output 1 (configurable)
3	GNDIN	Negative supply voltage (0 VDC)
4	SWIO2	Sw. input/output 2 (configurable)
5	FE	Functional earth
Thread (M12 plug) Cable gland	Functional earth	<p>Connection cable shield.</p> <p>The shield of the connection cable is on the thread of the M12 plug or on the screw fitting of the cable bushing.</p> <p>The thread or the screw fitting is part of the metallic housing.</p> <p>The housing is at the potential of the functional earth via pin 5.</p>

#### **⚠ CAUTION**

#### **UL applications!**

*For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).*

### Switching input/output:

The BE 901 PB is equipped with two, freely programmable, optically decoupled switching inputs/outputs, SWIO1 and SWIO2.

- The switching inputs can be used to activate various internal functions of the BE 901 PB (e.g., Measurement Stop/Start, Teach Preset and Reset Preset).
- The switching outputs can be used to signal the state of the BE 901 PB and to implement external functions independent of the superior control (e.g. position value/speed value invalid, position and speed limit value exceeded, device error).
- The control can use switching inputs/outputs as digital I/O's.

If no internal BE 901 PB function is connected to the switching inputs/outputs, the ports can be addressed as two inputs, two outputs or as one input and one output of a digital I/O component.



*The function as an input or output is set via PROFIBUS parameters (see chapter 8.5) or using the webConfig configuration tool (**CONFIGURATION > DEVICE > Switching inputs/outputs**, see chapter 9.3.4).*

*If SWIO1 or SWIO2 is to be used as digital input or output, the configuration must be performed in module 4 (see chapter 8.5.6) or module 5 (see chapter 8.5.7).*

---

### NOTICE

#### Maximum input current

↪ The input current of the respective switching input is maximum 8 mA.

---

### NOTICE

#### Maximum loading of the switching outputs

↪ Do not load the respective switching output of the BE 901 PB with more than 60 mA at + 18 ... 30 VDC in normal operation.

↪ Each configured switching output is short-circuit proof.



*The two switching inputs/outputs, SWIO1 and SWIO2, are configured as follows by default:*

*Switching output SWIO1: Position value invalid*

*Switching input SWIO2: Teach Preset*

---

### NOTICE

#### SWIO1 and SWIO2 as switching output

↪ At the outputs of the BE 901 PB (SWIO1 and SWIO2), no switching outputs may be connected from external sensors/devices.

*The switching output of the BE 901 PB may otherwise malfunction.*

## 7.4.2 HOST / BUS IN (Host/Bus input, PROFIBUS)

For the creation of a PROFIBUS network with multiple participants, the BE 901 PB is equipped with the incoming PROFIBUS interface HOST / BUS IN.

5-pin, M12-plug (B-coded) or terminal block for connecting to HOST / BUS IN.




Figure 7.4: HOST / BUS IN connection

Table 7.2: HOST / BUS IN pin assignment

Pin/terminal	Designation	Assignment
1	nc	Not connected
2	A (N)	PROFIBUS Receive Data/Transmit Data A-line (N)
3	GNDP	Data Ground
4	B (P)	PROFIBUS Receive Data/Transmit Data B-line (P)
5	FE	Functional earth
Thread (M12 plug) Cable gland	Functional earth (housing)	Connection cable shield. The shield of the connection cable is on the thread of the M12 plug or on the screw fitting of the cable bushing. The thread or the screw fitting is part of the metallic housing. The housing is at the potential of the functional earth via pin 5.

### NOTICE

#### Self-configured cables with PROFIBUS interface!

- ⚡ Ensure adequate shielding.
- ⚡ The entire interconnection cable must be shielded and earthed.
- ⚡ The signal lines must be stranded in pairs.

### 7.4.3 BUS OUT (bus output, PROFIBUS)

For the creation of a PROFIBUS network with multiple PROFIBUS participants, the BE 901 PB is equipped with the outgoing BUS OUT PROFIBUS interface. All other BE 901 PB devices are connected in series to the first BE 901 PB (see chapter 7.5).

5-pin, M12-socket (B-coded) or terminal block for connection to BUS OUT.




Figure 7.5: BUS OUT connection

Table 7.3: BUS OUT pin assignment

Pin/terminal	Designation	Assignment
1	VP	+5 V for bus termination
2	A (N)	PROFIBUS Receive Data/Transmit Data A-line (N)
3	GNDP	Data Ground
4	B (P)	PROFIBUS Receive Data/Transmit Data B-line (P)
5	FE	Functional earth
nc	-	Not connected
Thread (M12 plug) Cable gland	Functional earth (housing)	Connection cable shield. The shield of the connection cable is on the thread of the M12 plug or on the screw fitting of the cable bushing. The thread or the screw fitting is part of the metallic housing. The housing is at the potential of the functional earth via pin 5.

#### NOTICE

#### Self-configured cables with PROFIBUS interface!

- ✎ Ensure adequate shielding.  
The entire interconnection cable must be shielded and earthed.
- ✎ The signal lines must be stranded in pairs.

#### NOTICE

#### BUS OUT termination necessary at the last BE 901 PB bus participant!

If the termination is activated, the downstream bus cable is disconnected.

- ✎ Terminate the last physical PROFIBUS participant on the BE 901 MS PB connection hood with a terminating resistor on the BUS OUT socket; see chapter 13.3 "Terminating resistor".
- ✎ Terminate the last physical PROFIBUS participant on the BE 901 MK PB connection hood with slide switch T (ON position, see Figure 7.3).

## 7.4.4 Service USB

### NOTICE

#### Connection to PC!

- ↳ The service USB interface of the BE 901 PB can be connected to the USB interface on the PC with a standard USB cable (plug combination - Mini-B type / Type A).
- ↳ If possible, use the ready-made cables from TR-Electronic GmbH (see chapter 13.4 "Other accessories").

5-pin, Mini-B plug for connecting to the service USB.




Figure 7.6: Service USB connection

Table 7.4: BUS OUT pin assignment

Pin/terminal	Designation	Assignment
1	VB	Sense input
2	D-	Data -
3	D+	Data +
4	ID	Not connected
5	GND	Ground

### NOTICE

#### Self-configured cables!

- ↳ The entire USB connection cable must be shielded according to the USB specifications.
- ↳ The maximum cable length of 3 m must not be exceeded.

## 7.5 PROFIBUS topology

The wiring of the network is simple and economical since the network connection is looped through from one participant to the next.




Figure 7.7: Linear PROFIBUS topology

Up to 125 PROFIBUS participants can be networked.

On the connection hood, the address switch is used to assign a PROFIBUS address to each BE 901 PB.

### NOTICE

#### PROFIBUS termination

- ✎ Terminate the last physical PROFIBUS participant on the BE 901 MS PB connection hood with a terminating resistor on the BUS OUT socket; see chapter 13.3 "Terminating resistor".
- ✎ Terminate the last physical PROFIBUS participant on the BE 901 MK PB connection hood with slide switch T; see Figure 7.3.

## 7.6 Cable lengths and shielding

Observe the maximum cable lengths and the shielding types:

Connection	Interface	Max. cable length	Shielding
Service	USB	3 m	Shielding absolutely necessary acc. to USB specifications
PROFIBUS	PROFIBUS DP	Acc. to PNO specifications	Shielding absolutely necessary acc. to PNO specifications
Switching input		10 m	Not necessary
Switching output		10 m	Not necessary
Power supply unit		30 m	Not necessary



## 8 Commissioning – Basic configuration

As a rule, the BE 901 PB is configured via the PROFIBUS interface. The PROFIBUS address is set via the address switch of the BE 901 MS PB or BE 901 MK PB connection hood.

Parameter changes for test purposes and extended configurations for the timing for the position and speed measurements can be performed via the webConfig tool (see chapter 9).

### NOTICE

#### Observe for the configuration of PROFIBUS devices!

↳ **Always** perform the basic configuration using the GSD device master file.

*Download the appropriate file from the Internet or with the webConfig tool directly out of the BE 901 PB.*

*In process operation, only the parameters in the PROFIBUS modules set via the GSD file (or via the webConfig-Tool (HOME > INSTALLATION > GSD-file)) or the PROFIBUS default presets are in effect. Parameter changes made via the webConfig tool (see chapter 9) have no effect in PROFIBUS.*

*If you switch the BE 901 PB to the Service operating mode via the webConfig tool, the BE 901 PB is disconnected from the PROFIBUS. All parameters set via the GSD file initially remain in effect. Parameter changes can now be made via the webConfig tool for test purposes.*

*Settings configured with the webConfig tool are overwritten by the PROFIBUS master with the settings made via the GSD file upon connection to PROFIBUS or after deactivation of the Service operating mode.*

↳ Configuration data is saved in the device **and** in the connection hood.

### 8.1 Configuring the PROFIBUS interface

The BE 901 PB is designed as a PROFIBUS DP device for cyclical data exchange (V0). The BE 901 PB supports a data transmission rate of up to 12 Mbit/s.

The functionality of the BE 901 PB is defined via parameters which are organized in modules. The modules are part of the device master file (GSD).

Function range:

- PROFIBUS-DP slave
- Modular structure of the IO data
- Automatic baud rate detection up to 12 Mbit/s
- SYNC/FREEZE
- FailSafe Mode
- Device-specific diagnostic data
- No change of the slave address via the PROFIBUS

### 8.1.1 Communication profile

The PROFIBUS communication profile defines how participants serially transmit their data via the transmission medium.

Depending on the communication requirements, PROFIBUS offers suitable protocols and transfer methods:

- The BE 901 PB supports the PROFIBUS DP communication profile for automation systems and decentral periphery.  
PROFIBUS DP is designed for efficient data exchange on the field level.
- Services are defined for data exchange.  
PROFIBUS DP differentiates between the services using the data access points transmitted in the telegram header.
- Data exchange with the decentral devices occurs primarily cyclically.  
For configuration, operation, observation and alarm handling, acyclic communication services can be used as an option.
- The necessary communication functions are defined in the DP base functions

### 8.1.2 Bus-access processes

The PROFIBUS communication profiles (DP, FMS) use a uniform bus-access process. It is implemented by layer 2 of the OSI model.

PROFIBUS bus-access processes are the token-passing process and the master-slave process.

The processes can be mixed in order to create a multi-master system. The BE 901 PB functions both in a mono-master system as well as in a multi-master system.

Table 8.1: PROFIBUS bus-access processes

Process	Description	BE 901 PB
Token-passing process	The bus-access permission is distributed by means of a token: <ul style="list-style-type: none"><li>- The participant obtains permission to transmit with the token.</li><li>- The token wanders between the master devices in the ring in a permanently defined time frame.</li><li>- The token-passing process is used for communication between the masters.</li></ul>	No
Master-slave process	Various slave devices are assigned to one master device: <ul style="list-style-type: none"><li>- The master can address the slaves which are assigned to it and fetch messages from them.</li><li>- The master always has the initiative.</li></ul>	Yes

#### NOTICE

#### **No slave-to-slave communication for BE 901 PB!**

✎ The BE 901 PB does not support slave-to-slave communication.

The DPV2 PROFIBUS DP specification permits slave-to-slave communication.

### 8.1.3 Device types

The following device types exist for PROFIBUS DP:

- Master
- Slave



The BE 901 PB is defined as a slave device in the device master file (GSD file)!

### 8.1.4 Automatic baud rate detection

The PROFIBUS implementation of the BE 901 PB features automatic baud rate detection. The BE 901 PB uses this function and offers no possibility for manual or permanent adjustment. The following baud rates are supported:

Baud rate kbit/s	9.6	19.2	93.75	187.5	500	1500	3000	6000	12000
------------------	-----	------	-------	-------	-----	------	------	------	-------

Automatic baud rate detection is indicated in the device master file (GSD) of the BE 901 PB: Auto\_Baud\_supp = 1

### 8.2 Setting the PROFIBUS address

The PROFIBUS address is set on the connection hood with the help of two rotary switches and a slide switch:

- The PROFIBUS address must be individually set for each BE 901 PB on the connection hood.
- The set PROFIBUS address must be  $\geq 1$  and  $\leq 126$ . On delivery, the PROFIBUS address is set to 126.  
PROFIBUS address 126 may not be used for data communication; it may only be used temporarily for commissioning.




*The BE 901 PB does not support automatic address assignment via the PROFIBUS.*

#### **NOTICE**


#### **PROFIBUS termination!**

- ✎ *Connection hood BE 901 MS PB: terminate the last physical PROFIBUS participant with a terminating resistor on the BUS OUT socket (see chapter 13.3 "Terminating resistor").*
- ✎ *Connection hood BE 901 MK PB: terminate the last physical PROFIBUS participant with slide switch T on the connection hood (switch position ON).*



- 1: Slide switch T, PROFIBUS termination
- 2: Slide switch "x100", hundreds digit  
(ON = address 100 ... 126, OFF = address 1 ... 99 can be set)
- 3: Rotary switch "x10", tens digit
- 4: Rotary switch "x1", ones digit  
Factory settings: address 126

Figure 8.1: BE 901 MK PB connection hood, setting of the PROFIBUS address



- 1: Slide switch "x100", hundreds digit  
(ON = address 100 ... 126, OFF = address 1 ... 99 can be set)
- 2: Rotary switch "x10", tens digit
- 3: Rotary switch "x1", ones digit  
Factory settings: address 126

Figure 8.2: BE 901 MS PB connection hood, setting of the PROFIBUS address

### 8.3 Starting the device

To start the BE 901 PB:

- ✚ Set the PROFIBUS address on the connection hood of the BE 901 PB.
- ✚ Connect the supply voltage. The BE 901 PB starts up and, for devices with a display, the device status is displayed.
- ✚ Configure the BE 901 PB, e.g., for a Siemens SIMATIC-S7 control.

### 8.4 Configuring for the Siemens SIMATIC-S7 control

The BE 901 PB is designed as a PROFIBUS slave device.

The functionality of the BE 901 PB is defined via parameter sets which are organized in modules. The modules are part of the device master file (GSD), which is supplied as an integral part of the device.

By using a user-specific project tool, such as, e.g., SIMATIC Manager for the Siemens programmable logic control, the required modules are integrated into a project during commissioning and its settings and parameters are adjusted accordingly. These modules are provided by the GSD file.

During programming the control system (PLC) must be prepared for consistent data transmission.

---

#### **NOTICE**

#### **Observe SIMATIC Manager version!**

- ✚ *For the Siemens SIMATIC-S7 control, you need at least SIMATIC Manager version 5.4 + service pack 5 (V5.4+SP5).*

---

The following steps are necessary for commissioning:

- Preparation of the control system (S7 PLC)
- Installation of the GSD file

Proceed as follows:

- ✚ To prepare the control (S7 PLC):
  - Assign a PROFIBUS address to the control (S7 PLC).
  - Prepare the control system for consistent data transmission.
- ✚ Install the GSD file for the subsequent configuration of the BE 901 PB.
  - You can find the GSD file at [www.tr-electronic.com/f/TR-E-ID-MUL-0009](http://www.tr-electronic.com/f/TR-E-ID-MUL-0009).



*Alternatively, the GSD file can be loaded from the BE 901 PB with the webConfig tool (see chapter 9):*

**HOME > INSTALLATION > GSD file**

*The GSD file stored in the BE 901 PB is always compatible with the BE 901 PB.*

---

### General information on the GSD file

The term GSD (device master file) stands for the textual description of a PROFIBUS device model.

- Each GSD file supports one language.
- In the GSD file, all data necessary for operating the BE 901 PB is described in modules:
  - Input and output data
  - device parameters
  - definition of the control and status bits
- If parameters are changed in the project tool, for example, these changes are stored by the PLC in the project, not in the GSD file.



*The GSD file is an integral part of the device and must not be changed manually. The file is not changed by the system either.*

---

The functionality of the BE 901 PB is defined via GSD parameters. The parameters and their functions are structured in the GSD file using modules. A user-specific configuration tool is used during PLC program creation to integrate the required modules and configure them appropriately for their respective use.

During operation of the BE 901 PB on the PROFIBUS all parameters are set to default values. If these parameters are not changed by the user, the device functions with the default settings delivered by TR-Electronic GmbH. The default settings of the BE 901 PB can be found in the module descriptions.

### GSD file name structure

Each GSD file supports one language. The name of the GSD file of the BE 901 PB is structured as follows:

**TRE-0FA5.gs[x]**

**[x]** = language-specific code letter:

**d** (German)  
**e** (English)  
**f** (French)  
**i** (Italian)  
**s** (Spanish)

## 8.5 PROFIBUS project modules

From the perspective of the device, a distinction is made between interface-specific parameters and internal parameters:

- Interface-specific parameters  
Parameters that can be changed via the interface (see modules described in the following).
- Internal parameters  
Parameters that are changed only via a service interface.  
They retain their value even after the interface-specific configuration.

---

### NOTICE

#### **Overwriting of data by PLC!**

- ↳ *Note that the PLC overwrites the data set via the service interface.*
- ↳ *During the interface-specific configuration phase, all interface-specific parameters that were changed via the service interface are overwritten. This also applies for the parameters from modules that were not configured.*
- ↳ *During the configuration phase, the BE 901 PB receives parameter telegrams from the master.*  
*Before the parameter telegrams are evaluated and the respective parameter values are set, all interface-specific parameters are reset to default values. This ensures that the parameters of modules that are not selected are set to the default values.*

---

### NOTICE

#### **Do not activate any universal modules!**

- ↳ *If the control makes a so-called “universal module” available, the universal module may not be activated for the BE 901 PB.*



*You can find the default values of the BE 901 PB in the module descriptions.*

---

### 8.5.1 Overview of the modules

Module	Module name	Module contents (P) = Parameter, (O) = Output, (I) = Input
Device parameter modules see page 65	Position value	Profile (P), Integration depth (P), Tape selection (P)
<b>M1</b> see page 66	Position value	Sign (P), Unit (P), Position resolution (P), Counting direction (P), Offset (P), Position (I)
<b>M2</b> see page 67	Static preset	Preset value (P), Teach Preset (O), Reset Preset (O)
<b>M3</b> see page 68	Dynamic preset	Preset value (P), Teach Preset (O), Reset Preset (O)
<b>M4</b> see page 68	Input/output IO 1	Function (P), Activation (P), Output (P), Input (P), State (I), Control output (O)
<b>M5</b> see page 71	Input/output IO 2	Function (P), Activation (P), Output (P), Input (P), State (I), Control output (O)
<b>M6</b> see page 74	Status and control	Measurement value invalid/not active (I), Preset active (I), Teach Preset toggle (I), Lower/upper position limit value 1 ... 2 (I), Control/marker barcode detected (I), Control/ marker barcode toggle (I), Temperature warning/error (I) Hardware defect (I), Reading quality warning/Error threshold (I), Standby active (I), Start/stop measurement (O), Activate/deactivate Standby (O), Acknowledge control/marker barcode (O)
<b>M7</b> see page 76	Position limit value range 1	Upper/Lower pos. limit 1 (P)
<b>M8</b> see page 76	Position limit value range 2	Upper/Lower pos. limit 2 (P)
<b>M9</b> see page 76	Error handling procedures	Position value in the case of error (P), Suppress position state (P), Error delay/error delay time (position) (P), Speed in the case of error (P), Suppress speed state (P), Error delay/error delay time (speed) (P)
<b>M10</b> see page 77	Speed	Speed resolution (P), Averaging (P), Speed (I)
<b>M11</b> see page 78	Static speed limit value 1	Switching type (P), Selection of direction (P), Speed limit value 1 (P), Speed hysteresis 1 (P), Limit value 1 range start/range end (P)
<b>M12</b> see page 79	Static speed limit value 2	Switching type (P), Selection of direction (P), Speed limit value 2 (P), Speed hysteresis 2 (P), Limit value 2 range start/range end (P)
<b>M13</b> see page 79	Static speed limit value 3	Switching type (P), Selection of direction (P), Speed limit value 3 (P), Speed hysteresis 3 (P), Limit value 3 range start/range end (P)
<b>M14</b> see page 80	Static speed limit value 4	Switching type (P), Selection of direction (P), Speed limit value 4 (P), Speed hysteresis 4 (P), Limit value 4 range start/range end (P)
<b>M15</b> see page 81	Dynamic speed limit value	Limit value control (P), Switching type (P), selection of direction (P), Speed limit value (P), Hysteresis (P), Limit value range start/range end (P)

...



...

<b>M16</b> see page 81	Speed state	Speed measurement error (I), Speed limit value 1 ... 4 exceeded (I), Dynamic speed limit value exceeded (I), Movement status/direction (I), Speed limit value status 1 ... 4 active (I), Dynamic speed limit value active (I)
<b>M20</b> see page 83	Free resolution	Position (P), Speed (P)
<b>M21</b> see page 83	Distance to BCB	Distance (I)
<b>M22</b> see page 83	Control and marker barcodes	Reload (P), Transfer (P) First/second/third character (I)
<b>M23</b> see page 84	Tape value correction	Real length (P), Range start/end(P)
<b>M24</b> see page 85	Reading quality	Warning threshold/error threshold /reading quality smoothing (P), Reading quality (I)
<b>M25</b> see page 85	Device status	Device status (I)
<b>M26</b> see page 86	Extended status	Tape direction (I)
<b>M28</b> see page 86	16-bit position value	16-bit position value (I)

### 8.5.2 Device parameter module – Permanently defined parameters

On the PROFIBUS, parameters may be stored in modules or may be defined permanently in a PROFIBUS participant. Depending on the configuration tool, the permanently defined but adjustable parameters are called “common” parameters or device-specific parameters.

The common parameters must always be present. They are defined outside of the configuration modules and are thus linked to the base module.

#### **NOTICE**

#### **Set the tape selection!**

☞ Set the Tape selection parameter according to the used barcode tape grid:

- 30 mm grid for the BCB G30
- 40 mm grid for the BCB G40

Common parameters/device-specific parameters:



*Each PROFIBUS device must have a device parameter module.*

*The module contains device-specific parameters, but no input data and no output data.*

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Profile	0	Byte	2	2	-----		Defines the used device profile. <b>Note:</b> Currently, only the BE901 profile is stored. Thus, no selection is possible. Number of the activated profile. 2: BE901 profile
Integration depth	1.0 ... 1.4	Bit field	2 ... 16	8	Measurements		Number of successive measurements that the BE 901 PB uses for position determination.
Tape selection	1.5 ... 1.6	Bit field	1: 30 mm BCB G30 2: 40 mm BCB G40	2	-----		Changeover between barcode tape (BCB G30) with 30 mm grid and (BCB G40) with 40 mm grid.

### 8.5.3 Module 1 – Position value

Module for the output of the current position value. The module also includes the most important parameters for formatting the output value.

The module contains parameters (with parameter data length of 6 bytes) and input data (with consistent input data length of 4 bytes), but no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Sign	0.0	Bit	0 ... 1	0	-----		Output mode of the sign. Affects position value and speed output: 0: Two's complement 1: Sign + quantity
Unit	0.1	Bit	0 ... 1	0	-----		The selection of the measurement unit affects all values with measurement units. The parameter applies to all interfaces: 0: Metric (mm) 1: Inch (in)
Position resolution	0.2 ... 0.4	Bit	1 ... 6	4	mm	in/100	Resolution of the position value. Affects only the interface-specific output. The resolution has no effect on the set parameter values such as offset or preset: 001 = 1: 0.001 010 = 2: 0.01 011 = 3: 0.1 100 = 4: 1 101 = 5: 10 110 = 6: Free resolution
Counting direction	0.5	Bit	0 ... 1	0	-----		Count direction for position calculation or sign for speed calculation. The parameter affects all interfaces: 0: Positive 1: Negative

...

...

Offset	1 ... 4	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	Output value=measurement value+offset. The parameter affects all interfaces. <b>Note:</b> If a preset is active, this has priority over the offset.
--------	---------	----------------	--------------------------------	---	----	--------	--

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Position	0.0	sign 32 bit	-2,000,000,000 ... +2,000,000,000	0	Scaled		Current position.

## NOTICE

### Convert numerical values when changing the unit of measurement!

↳ If the unit of measurement is changed from metric to inch (or vice versa), previously entered numerical values (e.g. for offset, preset, limit values etc.) are not automatically converted.

Example: Offset = 10000 mm – after changing from metric to inch: Offset = 10000 inch/100

↳ Manually convert the numerical values when changing the unit of measurement.

## 8.5.4 Module 2 – Static preset

With the module, it is possible to specify a static preset as a parameter and to activate this preset value at a suitable position (Teach Preset). The preset value is deactivated using the Reset Preset function. If the preset is activated, a set offset (module 1) is not used for the calculation of the position value (module 1).

An activated preset is stored in the BE 901 PB and in the connection hood. In the event of a device exchange, the values in the connection hood are retained. In the event of a device exchange including the connection hood, the preset value must be reactivated at the intended position (Teach Preset).

The module contains parameters (with parameter data length of 4 bytes) and output data (with output data length of 1 byte), but no input data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Preset value	0	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	New position value for a teach event via the output data.

Output data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Preset teach	0.0	Bit	0 ... 1	---	-----		Reading of the preset value (output value = preset value): Transition 0 → 1: Teach Preset
Preset reset	0.1	Bit	0 ... 1	---	-----		Preset value is deactivated (output value = measurement value + offset): Transition 0 → 1: Reset Preset

### 8.5.5 Module 3 – Dynamic preset

With the module, it is possible to specify a dynamic preset as part of the output data and to activate this preset value at a suitable position (Teach Preset). The preset value is deactivated using the *Reset Preset* function. If the preset is activated, a set offset (module 1) is not used for the calculation of the position value (module 1).

A dynamic preset value can be ascertained at runtime in the PLC program and transmitted to the BE 901 PB. A static preset value (module 2) can only be stored in the configuration.

An activated preset is stored in the BE 901 PB and in the connection hood. In the event of a device exchange, the values in the connection hood are retained. In the event of a device exchange including the connection hood, the preset value must be reactivated at the intended position (Teach Preset).

The module contains output data (with output data length of 5 bytes), but no parameters and no input data.

Output data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Preset teach	0.0	Bit	0 ... 1	---	-----		Read in the preset value: Transition 0 → 1: Teach Preset
Preset reset	0.1	Bit	0 ... 1	---	-----		Preset value is deactivated: Transition 0 → 1: Reset Preset
Preset value	1	sign 32 bit	-10,000,000 ... +10,000,000	---	-----		New position value for a teach event via bit 0.0.

### 8.5.6 Module 4 – Input/output IO 1

This module is used to set the mode of operation of digital input/output IO 1. The connection can be used as either an input or an output.

The output is activated by various events in the device.

If used as an input, a device function is controlled by an external signal.

Alternatively, the connection can also be used decoupled from the device:

- If used as an input, the state of an external signal is transmitted to the control in the input data.
- If used as an output, the connection is operated via the output data.

The module contains parameters (with parameter data length of 4 bytes), input data (with input data length of 1 byte) and output data (with output data length of 1 byte).

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Function	0.0	Bit	0 ... 1	1	-----		Mode: 0: Input 1: Output
Activation	0.1	Bit	0 ... 1	1	-----		The parameter defines the level of the output at which the Output event occurs. 0: LOW (output), transition 1 → 0 1: HIGH (output), transition 0 → 1 If the I/O is configured as an input, it responds edge triggered.

...

...

Output						Event for activating the output. The individual functions are OR-linked to one another.
	1.0	Bit	0 ... 1	0	-----	<b>Position limit value 1:</b> If the position value lies outside of configured limit value range 1, the output is set: 0: OFF 1: ON
	1.1	Bit	0 ... 1	0	-----	<b>Position limit value 2:</b> If the position value lies outside of configured Limit value range 2, the output is set: 0: OFF 1: ON
	1.2	Bit	0 ... 1	0	-----	<b>Speed limit value:</b> If the speed value lies outside of the configured values, the output is set. 0: OFF 1: ON
	1.3	Bit	0 ... 1	0	-----	<b>Position value invalid:</b> If no valid position value can be ascertained because, e.g., no barcode tape is read or the barcodes are destroyed or soiled, the output is set. 0: OFF 1: ON
	1.4	Bit	0 ... 1	0	-----	<b>Speed value invalid:</b> The output is set if no valid speed can be calculated. 0: OFF 1: ON
	1.5	Bit	0 ... 1	0	-----	<b>Warning threshold reading quality:</b> If the ascertained reading quality is below the configured warning threshold, the output is set. 0: OFF 1: ON
	1.6	Bit	0 ... 1	0	-----	<b>Error threshold reading quality:</b> If the ascertained reading quality is below the configured error threshold, the output is set. 0: OFF 1: ON
	2.0	Bit	0 ... 1	0	-----	<b>Pseudo dynamic output:</b> The control can set and reset the output on the BE 901 PB via bit 0.0 in the output data 0: OFF 1: ON
	2.1	Bit	0 ... 1	0	-----	<b>Device error:</b> If the BE 901 PB detects a device error, the output is set. 0: OFF 1: ON

...

...

Output	2.2	Bit	0 ... 1	0	-----	<b>Speed limit value 1:</b> If the speed value 1 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.3	Bit	0 ... 1	0	-----	<b>Speed limit value 2:</b> If the speed value 2 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.4	Bit	0 ... 1	0	-----	<b>Speed limit value 3:</b> If the speed value 3 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.5	Bit	0 ... 1	0	-----	<b>Speed limit value 4:</b> If the speed value 4 lies outside of the configured values, the output is set. 0: OFF 1: ON
Input	3	Bit field	0 ... 3	0		<b>Internal functionality</b> that is triggered in the device. If no internal function is selected, the control can read the state of an arbitrary external signal via bit 0.0 of the input data. 0: No internal function 1: Stop/start measurement 2: Teach Preset 3: Reset Preset

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
State	0.0	Bit	0 ... 1	---	-----		Signal state of the input or output: 0: Input/output not active at signal level 1: Input/output active at signal level

Output data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Control output	0.0	Bit	0 ... 1	---	-----		Control of the output. The function must be activated/deactivated via the parameters: 0: Output not active at signal level 1: Output active at signal level

### Behavior of the BE 901 PB during measurement stop/start



If the scanning beam is incident on the BCB at the moment the laser diode is switched on, the BE 901 PB returns valid measurement values after approx. 10 ms.

If the BE 901 PB is reactivated from standby, the motor must first reach its nominal rotational speed. It takes a few seconds before the BE 901 PB returns any valid measurement values.

### 8.5.7 Module 5 – Input/output IO 2

This module is used to set the mode of operation of digital input/output IO 2. The connection can be used as either an input or an output.

The output is activated by various events in the device.

If used as an input, a device function is controlled by an external signal.

Alternatively, the connection can also be used decoupled from the device:

- If used as an input, the state of an external signal is transmitted to the control in the input data.
- If used as an output, the connection is operated via the output data.

The module contains parameters (with parameter data length of 4 bytes), input data (with input data length of 1 byte) and output data (with output data length of 1 byte).

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Function	0.0	Bit	0 ... 1	0	-----		Mode: 0: Input 1: Output
Activation	0.1	Bit	0 ... 1	1	-----		The parameter defines the level of the output at which the <i>Output</i> event occurs. 0: LOW (output), transition 1 → 0 1: HIGH (output), transition 0 → 1 If IO 2 is configured as an input, it responds edge triggered.
Output							Event for activating the output. The individual functions are OR-linked to one another.
	1.0	Bit	0 ... 1	0	-----		<b>Position limit value 1:</b> If the position value lies outside of configured Limit value range 1, the output is set: 0: OFF 1: ON
	1.1	Bit	0 ... 1	0	-----		<b>Position limit value 2:</b> If the position value lies outside of configured Limit value range 2, the output is set: 0: OFF 1: ON
	1.2	Bit	0 ... 1	0	-----		<b>Speed limit value:</b> If the speed value lies outside of the configured values, the output is set. 0: OFF 1: ON
	1.3	Bit	0 ... 1	0	-----		<b>Position value invalid:</b> If no valid position value can be ascertained because, e.g., no barcode tape is read or the barcodes are destroyed or soiled, the output is set. 0: OFF 1: ON

...

...

Output	1.4	Bit	0 ... 1	0	-----	<b>Speed value invalid:</b> The output is set if no valid speed can be calculated. 0: OFF 1: ON
	1.5	Bit	0 ... 1	0	-----	<b>Warning threshold reading quality:</b> If the ascertained reading quality is below the configured warning threshold, the output is set. 0: OFF 1: ON
	1.6	Bit	0 ... 1	0	-----	<b>Error threshold reading quality:</b> If the ascertained reading quality is below the configured error threshold, the output is set. 0: OFF 1: ON
	2.0	Bit	0 ... 1	0	-----	<b>Pseudo dynamic output:</b> The control can set and reset the output on the BE 901 PB via bit 0.0 in the output data 0: OFF 1: ON
	2.1	Bit	0 ... 1	0	-----	<b>Device error:</b> If the BE 901 PB detects a device error, the output is set. 0: OFF 1: ON
	2.2	Bit	0 ... 1	0	-----	<b>Speed limit value 1:</b> If the speed value 1 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.3	Bit	0 ... 1	0	-----	<b>Speed limit value 2:</b> If the speed value 2 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.4	Bit	0 ... 1	0	-----	<b>Speed limit value 3:</b> If the speed value 3 lies outside of the configured values, the output is set. 0: OFF 1: ON
	2.5	Bit	0 ... 1	0	-----	<b>Speed limit value 4:</b> If the speed value 4 lies outside of the configured values, the output is set. 0: OFF 1: ON
Input	3	unsign 8 bit	0 ... 3	0	-----	<b>Internal functionality</b> that is triggered in the device. If no internal function is selected, the control can read the state of an arbitrary external signal via bit 0.0 of the input data. 0: No internal function 1: Stop/start measurement 2: Teach Preset 3: Reset Preset



Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
State	0.0	Bit	0 ... 1	---	-----		Signal state of the input or output: 0: Input/output not active at signal level 1: Input/output active at signal level

Output data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Control output	0.0	Bit	0 ... 1	---	-----		Control of the output. The function must be activated via the parameters: 0: Output not active at signal level 1: Output active at signal level

#### **Behavior of the BE 901 PB during measurement stop/start**



*If the scanning beam is incident on the BCB at the moment the laser diode is switched on, the BE 901 PB returns valid measurement values after approx. 10 ms.*

*If the BE 901 PB is reactivated from standby, the motor must first reach its nominal rotational speed. It takes a few seconds before the BE 901 PB returns any valid measurement values.*

### 8.5.8 Module 6 – Status and control

The module signals various status information of the BE 901 PB. Various device functions are controlled via the output data.

The module contains input data (with input data length of 2 bytes) and output data (with output data length of 2 bytes), but no parameters.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Measurement value invalid	0.0	Bit	0 ... 1	0	-----		Signals that no valid measurement value can be ascertained. 0: Measurement value valid 1: Measurement value invalid
Measurement not active	0.1	Bit	0 ... 1		-----		Signals an inactive measurement. 0: Measurement active 1: Measurement not active
Preset active	0.2	Bit	0 ... 1	0	-----		Signals a position value output with active preset. 0: No preset active 1: Preset active
Teach Preset toggle	0.3	Bit	0 ... 1	0	-----		This toggle bit changes its state on each Teach Preset event. 0: OK 1: Value less than limit
Lower position limit value 1	0.4	Bit	0 ... 1	0	-----		Signals that the value is less than lower position limit 1. 0: OK 1: Value less than limit
Upper position limit value 1	0.5	Bit	0 ... 1	0	-----		Signals that upper position limit 1 has been exceeded. 0: OK 1: Value greater than limit
Lower position limit value 2	0.6	Bit	0 ... 1	0	-----		Signals that the value is less than lower position limit 2. 0: OK 1: Value less than limit
Upper position limit value 2	0.7	Bit	0 ... 1	0	-----		Signals that upper position limit 2 has been exceeded. 0: OK 1: Value greater than limit
Control or marker barcode detected	1.0	Bit	0 ... 1	0	-----		Signals a detected control or marker barcode. 0: No marker 1: Marker detected
Control or marker barcode toggle	1.1	Bit	1 ... 5	0	-----		This toggle bit changes its state on each detected control or marker barcode. 0, 1: New marker
Temperature warning	1.2	Bit	1 ... 5	0	-----		Signals that temperature is no longer within the specified temperature range. 0: OK 1: Temperature warning

...

...

Temperature error	1.3	Bit	0 ... 1	0	-----	Signals that the maximum permissible temperature has been exceeded. 0: OK 1: Temperature error
Hardware defect	1.4	Bit	0 ... 1	0	-----	Signals a hardware defect. 0: OK 1: Hardware defect
Warning threshold reading quality	1.5	Bit	0 ... 1	0	-----	Signals that the ascertained reading quality has dropped below the configured warning threshold. 0: OK 1: Value less than limit
Error threshold reading quality	1.6	Bit	0 ... 1	0	-----	Signals that the ascertained reading quality has dropped below the configured error threshold. 0: OK 1: Value less than limit
Standby active	1.7	Bit	0 ... 1	0	-----	Signals an active standby. 0: No standby 1: Standby active

Output data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Stopping/starting the measurement	0.0	Bit	0 ... 1	0	-----		With this bit, the measurement can be stopped and restarted. If the measurement is stopped, the BE 901 PB only deactivates the laser beam. If the measurement is restarted, measurement values are available again after a few milliseconds. 0: Measurement active 1: Stop measurement
Activate/deactivate standby	0.1	Bit	0 ... 1	0	-----		With this bit, the BE 901 PB can be switched to standby; the BE 901 PB deactivates laser beam and motor. If standby is then deactivated, the motor must first reach its nominal rotational speed; as a result, it takes several seconds before measurement values are available again. 0: Not active 1: Activate
Acknowledge control or marker barcode	0.2	Bit	0 ... 1	0	-----		With this bit, the acceptance of the detected control or marker barcode can be acknowledged to the PLC. Transition 0 → 1: Acknowledgment

### 8.5.9 Module 7 – Position limit value range 1

The module defines a position range with lower and upper limits. If the measured position value is outside of the configured range, the corresponding status bit is set in module 6 and, if configured, an output is set.

The module contains parameters (with parameter data length of 8 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Lower pos. limit 1	0 ... 3	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	Lower position limit.
Upper pos. limit 1	4 ... 7	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	Upper position limit.

### 8.5.10 Module 8 – Position limit value range 2

The module defines a position range with lower and upper limits. If the measured position value is outside of the configured range, the corresponding status bit is set in module 6 and, if configured, an output is set.

The module contains parameters (with parameter data length of 8 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Lower pos. limit 2	0 ... 3	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	Lower position limit.
Upper pos. limit 2	4 ... 7	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	Upper position limit.

### 8.5.11 Module 9 – Error handling procedures

The module makes parameters available to handle any errors should they occur.

If there is a brief disturbance in the position value or the speed calculation in the device, the BE 901 PB sends the last valid measurement value for a configured time.

If the BE 901 PB can again calculate valid measurement values within the error delay time, these are output. The disturbance is made evident only as a small increase in the output measurement value.

If the problem with the calculation lasts for a longer period of time, it is possible to configure how the BE 901 PB is to behave.

The module contains parameters (with parameter data length of 8 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Position value in the case of error	0.0 ... 0.1	Bit	0 ... 1	1	-----		Position value in the case of an error after the error delay time elapses: 0: Last valid value 1: Zero

...

...

Suppress position status	0.2	Bit	0 ... 1	1	-----	Status bit (module 6 bit 0.0) in the case of an error: 0: OFF (status bit is set immediately) 1: ON (status bit is suppressed for the configured error delay time)
Error delay (position)	0.3	Bit	0 ... 1	1	-----	Position value in the case of an error: 0: OFF (immediately the value of the Position value in the case of error parameter) 1: ON (the last valid position value for the configured error delay time)
Error delay time (position)	1 ... 2	unsign 16 bit	10 ... 4,000	50	1 ms	Errors that occur are suppressed for the configured time, i.e., if no valid position value can be ascertained in the configured time, the last valid position value is always output. If the error persists after the time elapses, the value of the Position value in the case of error parameter is output.
Speed in the case of failure	3.0 ... 3.1	Bit	0 ... 1	1	-----	Speed value in the case of an error after the error delay time elapses (speed): 0: Last valid value is output 1: Zero is output
Suppress speed status	3.2	Bit	0 ... 1	1	-----	Status bit (module 16 bit 0.0) in the case of an error: 0: OFF (status bit is set immediately) 1: ON (status bit is suppressed for the configured error delay time)
Error delay (speed)	3.3	Bit	0 ... 1	1	-----	Speed in the case of an error: 0: OFF (immediately outputs the value of the Speed in the case of error parameter) 1: ON (outputs the last valid speed for the configured error delay time)
Error delay time (speed)	4 ... 5	unsign 16 bit	10 ... 4,000	50	1 ms	Errors that occur are suppressed for the configured time, i.e., if no valid speed can be ascertained in the configured time, the last valid speed is always output. If the error persists after the time elapses, the value of the Speed in the case of error parameter is output.

### 8.5.12 Module 10 – Speed

The module is used to output the current speed in the desired resolution.

The unit (metric or inch) is set via module 1 (position value) and also applies to the speed. If module 1 is not configured, the value is output with the default unit of measurement (metric). The sign of the speed is dependent on the count direction selected in module 1. With the default counting direction (positive), a positive speed is output for movement towards larger tape values. Movement towards smaller tape values results in negative velocities. Measurement value preparation averages all speed values calculated during the selected period (averaging) to yield a speed output value.

The module contains parameters (with parameter data length of 2 bytes) and input data (with consistent input data length of 4 bytes), but no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Speed resolution	0.0 ... 0.2	Bit	1 ... 5	1	mm/s	(in/100)/s	Resolution for the speed value: 001 = 1: 010 = 2: 10 011 = 3: 100 100 = 4: 1000 101 = 5: Free resolution
Averaging	0.3 ... 0.5	Bit	0 ... 5	2	-----		All calculated velocities are averaged over the specified time: 000 = 0: No averaging 001 = 1: 2 ms 010 = 2: 4 ms 011 = 3: 8 ms 100 = 4: 16 ms 101 = 5: 32 ms

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Speed	0	sign 32 bit	-1,000,000 ... +1,000,000	0	scaled		Current speed.

### 8.5.13 Module 11 – Static speed limit value 1

The module provides all parameters for the Static speed limit value 1 function.

This function compares the current speed with a limit speed stored via the configuration. The comparison takes place in the configured range, which is defined by the *Range start* and *Range end* parameters.

If a direction-dependent limit value check is activated via the *Direction selection* parameter, the values of the *Range start* and *Range end* parameters also define the direction. The check is always performed from range start to range end.

Example: If the range start is 5500 and the range end is 5000, the direction-dependent check is only performed in the direction from 5500 to 5000. The limit value is not active in the opposite direction.

If the check is independent of direction, the order of range start and range end is irrelevant. Depending on the selected switching mode, if the value is above or below the defined limits, the limit value status in module 16 (see chapter 8.5.18) is set and, if configured, the switching output is appropriately set via module 4 (see chapter 8.5.6) or module 5 (see chapter 8.5.7).

If the range start is identical to the range end, a continuous, direction-independent limit value check is performed.

The module contains parameters (with parameter data length of 13 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Switching type	0.0	Bit	0 ... 1	0	-----		Condition for the Speed limit value 1 signal, which applies to the switching output (module 4/5) and the status bit (module 16): 0: Exceeded 1: Below minimum value
Direction selection	0.1	Bit	0 ... 1	0	-----		Selection of the limit value check: 0: Direction independent 1: Direction dependent

...

...

Speed limit value 1	1 ... 2	unsign 16 bit	0 ... +20,000	0	mm/s	(in/100)/s	Limit value is compared to the current speed.
Speed hysteresis 1	3 ... 4	unsign 16 bit	0 ... 1,000	100	mm/s	(in/100)/s	Relative shift of the switching point to prevent signal bouncing.
Limit value 1 range start	5 ... 8	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored beginning at this position.
Limit value 1 range end	9 ... 12	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored up to this position.

### 8.5.14 Module 12 – Static speed limit value 2

The module provides all parameters for the Static speed limit value 2 function.

Further explanations on the Range start and Range end parameters see chapter 8.5.13 "Module 11 – Static speed limit value 1".

The module contains parameters (with parameter data length of 13 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Switching type	0.0	Bit	0 ... 1	0	-----		Condition for the Speed limit value 2 signal, which applies to the switching output (module 4/5) and the status bit (module 16): 0: Exceeded 1: Below minimum value
Direction selection	0.1	Bit	0 ... 1	0	-----		Selection of the limit value check: 0: Direction independent 1: Direction dependent
Speed limit value 2	1 ... 2	unsign 16 bit	0 ... +20,000	0	mm/s	(in/100)/s	Limit value is compared to the current speed.
Speed hysteresis 2	3 ... 4	unsign 16 bit	0 ... 1,000	100	mm/s	(in/100)/s	Relative shift of the switching point to prevent signal bouncing.
Limit value 2 range start	5 ... 8	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored beginning at this position.
Limit value 2 range end	9 ... 12	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored up to this position.

### 8.5.15 Module 13 – Static speed limit value 3

The module provides all parameters for the Static speed limit value 3 function.

Further explanations on the Range start and Range end parameters see chapter 8.5.13 "Module 11 – Static speed limit value 1".

The module contains parameters (with parameter data length of 13 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Switching type	0.0	Bit	0 ... 1	0	-----		Condition for the Speed limit value 3 signal, which applies to the switching output (module 4/5) and the status bit (module 16): 0: Exceeded 1: Below minimum value
Direction selection	0.1	Bit	0 ... 1	0	-----		Selection of the limit value check: 0: Direction independent 1: Direction dependent
Speed limit value 3	1 ... 2	unsign 16 bit	0 ... +20,000	0	mm/s	(in/100)/s	Limit value is compared to the current speed.
Speed hysteresis 3	3 ... 4	unsign 16 bit	0 ... 1,000	100	mm/s	(in/100)/s	Relative shift of the switching point to prevent signal bouncing.
Limit value 3 range start	5 ... 8	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored beginning at this position.
Limit value 3 range end	9 ... 12	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored up to this position.

### 8.5.16 Module 14 – Static speed limit value 4

The module provides all parameters for the Static speed limit value 4 function.

Further explanations on the Range start and Range end parameters see chapter 8.5.13 "Module 11 – Static speed limit value 1"

The module contains parameters (with parameter data length of 13 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Switching type	0.0	Bit	0 ... 1	0	-----		Condition for the Speed limit value 4 signal, which applies to the switching output (module 4/5) and the status bit (module 16): 0: Exceeded 1: Below minimum value
Direction selection	0.1	Bit	0 ... 1	0	-----		Selection of the limit value check: 0: Direction independent 1: Direction dependent
Speed limit value 4	1 ... 2	unsign 16 bit	0 ... +20,000	0	mm/s	(in/100)/s	Limit value is compared to the current speed.
Speed hysteresis 4	3 ... 4	unsign 16 bit	0 ... 1,000	100	mm/s	(in/100)/s	Relative shift of the switching point to prevent signal bouncing.
Limit value 4 range start	5 ... 8	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored beginning at this position.
Limit value 4 range end	9 ... 12	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored up to this position.



### 8.5.17 Module 15 – Dynamic speed limit value

The module provides the dynamic speed limit value function via output data.

The dynamic speed limit value function compares the current speed with a limit speed stored via the output data. The speed limit value can be dynamically changed, i.e., at runtime via the control program.

The speed comparison takes place in a range defined via the output data. Further explanations on the Range start and Range end parameters see chapter 8.5.13 "Module 11 – Static speed limit value 1".

The module contains output data (with parameter data length of 13 bytes), but no input data and no parameters.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Limit value control	0.0	Bit	0 ... 1	---	-----		Controls internal processing of the transferred dynamic limit value parameters: 0: Do not process 1: Parameter now valid / process
Switching type	0.1	Bit	0 ... 1	---	-----		Condition for the signal change of the switching output/status bit: 0: Speed limit value exceeded 1: Speed limit value not met
Direction selection	0.2	Bit	0 ... 1	---	-----		Selection of the limit value check: 0: Direction independent 1: Direction dependent
Speed limit value	1 ... 2	unsign 16 bit	0 ... +20,000	---	mm/s	(in/100)/s	Limit value is compared to the current speed.
Hysteresis	3 ... 4	unsign 16 bit	0 ... 1,000	---	mm/s	(in/100)/s	Relative shift of the switching point to prevent signal bouncing.
Limit value range start	5 ... 8	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored beginning at this position.
Limit value range end	9 ... 12	sign 32 bit	-10,000,000 ... +10,000,000	0	mm	in/100	The speed limit value is monitored up to this position.

### 8.5.18 Module 16 – Speed status

The module supplies the interface master with various status information for speed measurement via input data.

The module contains input data (with input data length of 2 bytes), but no parameters and no output data.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Speed measurement error	0.0	Bit	0 ... 1	---	-----		Signals that no valid speed could be ascertained: 0: No speed limit value violation 1: Speed limit value violation
Speed limit value 1 exceeded	0.1	Bit	0 ... 1	---	-----		Signals that speed limit value 1 has been exceeded: 0: No limit value violation 1: Value greater than limit

...

...

Speed limit value 2 exceeded	0.2	Bit	0 ... 1	---	-----	Signals that speed limit value 2 has been exceeded: 0: No limit value violation 1: Value greater than limit
Speed limit value 3 exceeded	0.3	Bit	0 ... 1	---	-----	Signals that speed limit value 3 has been exceeded: 0: No limit value violation 1: Value greater than limit
Speed limit value 4 exceeded	0.4	Bit	0 ... 1	---	-----	Signals that speed limit value 4 has been exceeded: 0: No limit value violation 1: Value greater than limit
Dynamic speed limit value exceeded	0.5	Bit	0 ... 1	---	-----	Signals that the dynamic speed limit value has been exceeded: 0: No limit value violation 1: Value greater than limit
Movement status	0.6	Bit	0 ... 1	---	-----	Signals whether a movement > 0.1 m/s is currently being detected: 0: No movement 1: Movement
Direction of movement	0.7	Bit	0 ... 1	---	-----	If bit 1 (movement status) is set, this bit indicates the direction: 0: Positive direction 1: Negative direction
Speed limit value 1 active	1.1	Bit	0 ... 1	---	-----	Signals whether the current speed is compared with the Speed limit value 1: 0: Comparison not active 1: Comparison active
Speed limit value 2 active	1.2	Bit	0 ... 1	---	-----	Signals whether the current speed is compared with the Speed limit value 2: 0: Comparison not active 1: Comparison active
Speed limit value 3 active	1.3	Bit	0 ... 1	---	-----	Signals whether the current speed is compared with the Speed limit value 3: 0: Comparison not active 1: Comparison active
Speed limit value 4 active	1.4	Bit	0 ... 1	---	-----	Signals whether the current speed is compared with the Speed limit value 4: 0: Comparison not active 1: Comparison active
Dynamic speed limit value active	1.5	Bit	0 ... 1	---	-----	Signals whether the current speed is compared with the Dynamic speed limit value: 0: Comparison not active 1: Comparison active

### 8.5.19 Module 20 – Free resolution

The module is used to implement two parameters that facilitate free scaling of the output values for position value and speed value.

The free resolution is used if the adjustable resolutions that can be set in module 1 or module 10 are not suitable for the application. In modules 1 and 10, the *Resolution* parameter is set to value *Free resolution*. The measurement values are then converted for output with (multiplied by) the parameter values stored in this module and output.

The module contains parameters (with parameter data length of 4 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Position	0 ... 1	unsign 16 bit	5 ... 50,000	1000	mm/1000	in/100000	Free resolution of the position value: Applies for all interfaces that selected the value free resolution as resolution.
Speed	2 ... 3	unsign 16 bit	5 ... 50,000	1000	(mm/1000)/s	(in/100000) /s	Free resolution of the speed value. Applies for all interfaces that selected the value free resolution as resolution.

### 8.5.20 Module 21 – distance to the barcode tape (BCB)

The module enables the transmission of the current distance between the BCB and read head (in mm) to the interface master.

This can be used to check the correct reading distance in the entire system.

Example: A fault in the position value determination is caused by an impermissible reading distance at this location.

If value 255 is transmitted, a reading distance outside of the permissible reading field was calculated.

If value 0 is transmitted, a valid distance could not be calculated.

The module contains input data (with input data length of 1 byte), but no parameters and no output data.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Distance	0	unsign 8 bit	0 ... 255	0	mm	in/10	Current distance between BCB and read head: 0: No distance calculated 255: Distance outside of the reading field

### 8.5.21 Module 22 – Control and marker barcodes

The module enables the transmission of control and marker information to the interface master and setting of the corresponding parameters.

The module contains parameters (with parameter data length of 1 byte) and input data (with input data length of 3 bytes), but no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Reload	0.0	Bit	0 ... 1	0	-----		Configuration for input data: 0: Immediately overwrite input data 1: Overwrite input data after acknowledgment
Transmission	0.1	Bit field	0 ... 2	0	-----		Configuration of which information is transmitted in the input data: 0: Control and marker barcodes 1: Only marker barcodes 2: Only control barcodes

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
First character	0	unsign 8 bit	0 ... 255	0	-----		First character of the detected control or marker barcode.
Second character	1	unsign 8 bit	0 ... 255	0	-----		Second character of the detected control or marker barcode.
Third character	2	unsign 8 bit	0 ... 255	0	-----		Third character of the detected control or marker barcode.

### 8.5.22 Module 23 – Tape value correction

The module enables the *Tape value correction* functionality for correcting the deviation of the BCB from the correct (calibrated) millimeter scaling that results from the manufacturing process.

A suitable measuring device must be used to determine the real (calibrated) length of one meter of barcode tape (as printed). If, for example, one meter of tape corresponds to an actual (calibrated) length of 1001.4 mm, the value 10014 is entered in the *Real length* parameter of this module. The real length is specified with a resolution of 0.1 millimeters.

To use the exact resolution, it is useful to measure a longer section of BCB and convert the deviation to a length of one meter.

The *Range start* parameter must be configured according to the real starting value of the used barcode tape. If multiple, different BCBs are pieced together, the *Range end* parameter of the corrected section of tape must also be configured. The entire BCB is corrected with the default value of 10,000,000 for the range end.

The module contains parameters (with parameter data length of 10 bytes), but no input data and no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Real length	0	unsign 16 bit	0 ... 65,535	10,000	mm/10		Real (calibrated) length of one meter of BCB (according to imprint).
Range start	2	unsign 32 bit	0 ... 10,000,000	0	mm		The tape value is corrected with the Real length starting from this position.
Range end	6	unsign 32 bit	0 ... 10,000,000	10,000,000	mm		The tape value is corrected with the Real length up to this position.

### 8.5.23 Module 24 – Reading quality

The module enables the Reading quality functionality for transmitting the BE 901 PB reading quality and for configuring the parameters for warning threshold, error threshold and smoothing of the reading quality.

By transmitting the reading quality, continuous monitoring is possible. The operator can immediately see when the reading quality deteriorates due to wear or soiling.



#### **Correct calculation of the reading quality**

*The evaluation of the reading quality is influenced by several factors, see chapter 4.5 “Evaluation of the reading quality”.*

The signaling of the reading quality is configured via the status information in module 6 (see chapter 8.5.8) and via the switching output functions in module 4 (see chapter 8.5.6) or module 5 (see chapter 8.5.7).

The module contains parameters (with parameter data length of 2 bytes) and input data (with input data length of 1 byte), but no output data.

Parameter	Rel. addr.	Data type	Value range	Default	Unit		Explanation
					Metr.	Inch	
Warning threshold reading quality	0	unsign 8 bit	30 ... 90	60	-----		Below this threshold for reading quality in units of [%], the BE 901 PB generates a warning event.
Error threshold reading quality	1	unsign 8 bit	10 ... 70	30	-----		Below this threshold for reading quality in units of [%], the BE 901 PB generates an error event.
Reading quality smoothing	2	unsign 8 bit	0 ... 100	5	-----		Insensitivity towards changes of the quality. The higher this value is, the less of an effect a change has on the reading quality.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Reading quality	0	unsign 8 bit	0 ... 100	0	%	%	Reading quality in units of [%] as smoothed value, dependent on the Smoothing of reading quality parameter.

### 8.5.24 Module 25 – Device status

The module signals various device states via input data.

The module contains input data (with input data length of 1 byte), but no parameters and no output data.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Device status	0	unsign 8 bit	0: Initial value 1: Initialization 10: Standby 11: Service 12: Diagnostics 15: Device is ready 128: Error 129: Warning	0	-----		This byte represents the current device status. The following event messages can be acknowledged via "Module 6 – Status and control" (output data bit 0.3): 128: Error 129: Warning
Input data length: 1 byte							

### 8.5.25 Module 26 – Extended status

Via input data, the module signals various pieces of extended status information, such as the current read direction of the barcode tape.

The module contains input data (with input data length of 2 bytes), but no parameters and no output data.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Explanation
					Metr.	Inch	
Increasing tape direction	0.0	bit	0: Not increasing 1: Increasing	0	-----		The orientation between BE 901 PB and barcode tape (BCB) results in an increasing read direction. If bits 0.0 and 0.1 are not set (0), no read direction can currently be determined.
Decreasing tape direction	0.1	bit	0: Not decreasing 1: Decreasing	0	-----		The orientation between BE 901 PB and barcode tape (BCB) results in a decreasing read direction. If bits 0.0 and 0.1 are not set (0), no read direction can currently be determined.
Input data length: 2 bytes							

### 8.5.26 Module 28 - 16-bit position value

Module for the output of the current position value as 16-bit value. The resolution of the position value is fixed and is one decimeter (100 mm) or one inch (in).

The display of the sign and the measurement unit can be changed in module 1 (see chapter 8.5.3).

In the default setting, the display is in two's complement and with metric units. If the 16-bit value range is exceeded, e.g., above an output value of 3.27675 km (= 32768 dm), the value zero (0) is transmitted as position value in this module.

The module contains input data (with input data length of 2 bytes), but no parameters and no output data.

Input data	Rel. addr.	Data type	Value range	Init value	Unit		Description
					Metr.	Inch	
16-bit position value	0	sign 16 bit	With two's complement: -32768 ... 32767 With sign and magnitude: -32767 ... 32767	0	dm (100 mm)	inch	Position value as 16-bit value with fixed resolution of one decimeter (100 mm) or one inch (in).
Input data length: 2 bytes							

## 9 Commissioning – webConfig tool

The webConfig tool provides a graphical user interface based on web technology for the configuration of the BE 901 PB.

The webConfig tool can be run on any Internet-ready PC. The webConfig tool uses HTTP as communication protocol and the client-side restriction to standard technologies (HTML, JavaScript and AJAX) that are supported by modern browsers.



The webConfig tool is offered in the following languages:  
German, English, French, Italian, Spanish

### NOTICE

#### Configuration changes via the webConfig tool have no effect in PROFIBUS!

✎ **Always** perform the basic configuration using the GSD file (see chapter 8 "Commissioning – Basic configuration").

*In process operation, only the parameters in the PROFIBUS modules set via the GSD file or the PROFIBUS default presets are in effect. Parameter changes made via the webConfig tool are no longer in effect on the PROFIBUS.*

*The parameters for the timing of the switching inputs/outputs can only be adjusted with the webConfig tool.*

*If you switch the BE 901 PB to the Service operating mode via the webConfig tool, the BE 901 PB is disconnected from the PROFIBUS. All parameters set via the GSD file initially remain in effect. Parameter changes can now be made via the webConfig tool for test purposes.*

*Settings configured with the webConfig tool are overwritten by the PROFIBUS master with the settings made via the GSD file upon connection to PROFIBUS or after deactivation of the Service operating mode. Settings that cannot be configured via PROFIBUS, e.g., timing functions, are not overwritten.*

### NOTICE

#### BE 901 PB configuration via webConfig tool

✎ The webConfig tool displays **no** PROFIBUS parameters.

✎ The configuration data is saved in the device **and** in the connection hood.

## 9.1 Installing software

In order for the BE 901 PB to be automatically detected by the connected PC, the USB driver must be installed once on your PC. Administrator rights are required for driver installation.



*If a USB driver for the webConfig tool is already installed on your computer, the USB driver does not need to be installed again.*

### 9.1.1 System requirements

---



*Regularly update the operating system and the Internet browser.  
Install the current Windows Service Packs.*

---

**Table 9.1: webConfig system requirements**

Operating system	Windows 10 Windows 8, 8.1 Windows 7
Computer	PC, Laptop or Tablet with USB interface version 1.1 or higher
Graphics card	Min. 1280 x 800 pixels
Required disk space for USB driver	10 MB
Internet browser	A current version of: - Mozilla Firefox - Google Chrome - Microsoft Edge  Other Internet browsers are possible, but not tested with the current device firmware.

### 9.1.2 Install USB driver

- ✚ Start your PC with administrator privileges and log on.
- ✚ Download the setup program from the Internet:  
[www.tr-electronic.com/f/zip/TR-E-SW-MUL-0001](http://www.tr-electronic.com/f/zip/TR-E-SW-MUL-0001)
- ✚ Start the setup program and follow the instructions.



*Alternatively you can install the USB driver **LEO\_RNDIS.inf** manually.  
Contact your network administrator if the installation failed.*

---



## 9.2 Start webConfig tool

Prerequisite: The USB driver for the webConfig tool is installed on the PC.

↗ Connect the operating voltage to the BE 901 PB.

↗ Connect the SERVICE USB interface of the BE 901 PB to the PC.

The connection to the SERVICE USB interface of the BE 901 PB is established via the PC-side USB interface.

Use a standard USB cable with one Type A plug and one Mini-B type plug.

↗ Start the webConfig tool using your PC's Internet browser with IP address

[192.168.61.100](http://192.168.61.100)

➤ The webConfig start page appears on your PC.



*The webConfig tool is completely contained in the firmware of the BE 901 PB.*

*The pages and functions of the webConfig tool may appear and be displayed differently depending on the firmware version.*

---

### Clearing browser history:

The cache of the Internet browser must be deleted if different device types or devices with different firmware have been connected to the webConfig tool.

↗ Delete cookies and temporary Internet and website data from the browser history before starting the webConfig tool.

### Note limit of Firefox sessions for version 30.0 and higher:

If the limited number of Firefox sessions is exceeded, it may no longer be possible to address the BE 901 PB via the webConfig tool.

↗ Do **not** use the refresh functions of the Internet browser: [Shift] [F5] or [Shift] + mouse click

### 9.3 Short description of the webConfig tool

#### 9.3.1 Overview

##### Operating modes

For configurations with the webConfig tool, you can switch between the following operating modes:

- **Process**

The BE 901 PB is connected to the control.

- The process communication to the control is activated.
- The switching inputs/outputs are activated.
- Configuration and diagnostic functions available, cannot be changed.
- *PROCESS* function available.
- Alignment and maintenance function not available.

- **Service**

The process communication to the control is interrupted.

- The switching inputs/outputs are deactivated.
- The configuration can be changed.
- *PROCESS* function not available.
- Alignment, configuration, diagnostic and maintenance functions available.

##### Operating mode **Process**

The webConfig tool has the following main menus or functions in the operating mode *Process*:

- **PROCESS**

Check and save the current read data in process mode (see chapter 9.3.2).

- Tabular display of the following values:  
Scan number, position, speed, reading quality, distance from BCB and info on the control label

- **CONFIGURATION** (see chapter 9.3.4)

Information on the current BE901 configuration – no change to the configuration:

- Selection of the used barcode tape (30 mm grid or 40 mm grid)
- Display of the tape value correction (deviation of the BCB from scaling)
- Display of the device components (switching inputs/outputs, display)
- Data processing (position / speed detection or monitoring, data preparation)
- Display of the warning threshold and the error threshold for the reading quality
- Display of the interface parameters

##### Operating mode **Service**

The webConfig tool has the following main menus or functions in the operating mode *Service*:

- **ALIGNMENT** (see chapter 9.3.3)

- Display of the following values:  
Scan number, position, speed, quality, distance, number of labels in the scanning beam
- Graphical displays of the following values:  
Position, speed, quality


- **CONFIGURATION** (see chapter 9.3.4)
  - Configuration of device components (switching inputs/outputs, display)
  - Selection of the used barcode tape
  - Configuration of the data processing (position / speed detection or monitoring, data preparation)
  - Configuration of the warning threshold and the error threshold for the reading quality
  - Configuration of the interface parameters
- **DIAGNOSTICS** (see chapter 9.3.5)
  - Event logging of warnings and errors.
- **MAINTENANCE** (see chapter 9.3.6)
  - Firmware update
  - User management
  - Backup/Restore

### 9.3.2 PROCESS function

The *PROCESS* function serves to control the current measurement data in the *Process* operating mode.

The measurement results are output in tabular form – strictly as monitor output.

The **Pause/Start** icon can be used to interrupt and resume monitor recording.



Index	Scan number	Position [mm]	Speed [mm/s]	Quality [%]	Distance [mm]	Info	Tape change
856	157878	0	0	0	0	-	-
857	157893	0	0	0	0	-	-
858	157908	0	0	0	0	-	-
859	157923	0	0	0	0	-	-
860	157938	0	0	0	0	-	-
861	157953	0	0	0	0	-	-
862	157968	0	0	0	0	-	-
863	157983	0	0	0	0	-	-
864	157998	0	0	0	0	-	-
865	158013	0	0	0	0	-	-
866	158028	0	0	0	0	-	-
867	158043	0	0	0	0	-	-
868	158058	0	0	0	0	-	-
869	158073	0	0	0	0	-	-
870	158088	0	0	0	0	-	-
871	158103	0	0	0	0	-	-
872	158118	0	0	0	0	-	-
873	158133	0	0	0	0	-	-
874	158148	0	0	0	0	-	-
875	158163	0	0	0	0	-	-
876	158178	0	0	0	0	-	-
877	158193	0	0	0	0	-	-
878	158208	0	0	0	0	-	-
879	158223	0	0	0	0	-	-
880	158238	0	0	0	0	-	-
881	158253	0	0	0	0	-	-
882	158268	0	0	0	0	-	-
883	158283	0	0	0	0	-	-
884	158298	0	0	0	0	-	-
885	158313	0	0	0	0	-	-
886	158328	0	0	0	0	-	-
887	158343	0	0	0	0	-	-
888	158358	0	0	0	0	-	-
889	158373	0	0	0	0	-	-
890	158388	0	0	0	0	-	-
891	158403	0	0	0	0	-	-
892	158418	0	0	0	0	-	-

Figure 9.1: *PROCESS* webConfig function

## 9.3.3 ALIGNMENT function

### NOTICE

**ALIGNMENT function only in the Service operating mode!**

↳ The BE 901 PB can only be aligned using the ALIGNMENT function in the Service operating mode.

The **ALIGNMENT** function serves to simplify mounting and alignment of the BE 901 PB. The laser is to be activated via the **Start** icon so that the function can monitor and directly display the measurement values for position and speed and determine the optimum installation location.

In addition, reading quality (in %), working distance and the number of labels in the scanning beam can be displayed. Using this information, it is possible to assess how well the BE 901 PB is aligned with the BCB.



During output of the read results, the BE 901 PB is controlled by the webConfig tool.




Figure 9.2: **ALIGNMENT** webConfig function

## 9.3.4 CONFIGURATION function

### NOTICE

**Configuration changes only in the Service operating mode!**

↳ Changes made using the **CONFIGURATION** function can only be performed in the Service operating mode.

## Overview of the webConfig configuration functions:




Figure 9.3: CONFIGURATION webConfig function

### Configuration of the switching inputs/outputs (DEVICE tab):

- I/O mode: switching input or switching output \*
- Output function \*
- Function input \*
- Timing functions
  - Signal delay \*\*
  - Pulse duration \*\*
  - Switch-on/switch-off delay \*\*
  - Debounce time \*\*
  - Inversion yes/no \*



webConfig configuration parameters

\*: PROFIBUS parameters, see chapter 8.5

\*\*.: Parameter can only be configured via webConfig

## NOTICE

### Start-up configuration of the switching inputs and outputs!

- ✎ The configuration for switching inputs and outputs SWIO 1 and SWIO 2 is generally performed via the GSD file.


The settings configured with the webConfig tool that differ from the GSD configuration are overwritten on startup by the PROFIBUS master with the settings made via the GSD file. Settings that cannot be configured via PROFIBUS, e.g. timing functions, are not overwritten.

- ✎ The PROFIBUS modules 4 and 5 configure switching inputs and outputs (I/O's) SWIO 1 and SWIO 2 (see chapter 8.5.6 and see chapter 8.5.7), e.g.:
  - whether SWIO 1 and SWIO 2 operate as input or output
  - which events act on the output
  - the function of the input

### Timing functions of the switching inputs/outputs:

The timing functions (e.g., startup delay) can **only** be configured with the webConfig tool. The configuration of the timing functions is not overwritten by the PROFIBUS master on startup.

- Start-up delay  
With this setting, the output pulse is delayed by the specified time (in ms).
- Switch-on time  
Defines the switch-on time period for the switching input. Any activated switch-off function then no longer has any function.  
If the output is deactivated via the switch-off signal before the startup delay lapses, only a brief pulse appears at the output following the startup delay.



- 1: Start-up signal
- 2: Switch-off signal
- 3: Output
- 4: Start-up delay
- 5: Switch-on time

Figure 9.4: Start-up delay > 0 and switch-on time > 0

- Debounce time  
Parameter for setting the software debounce time for the switching input. The definition of a debounce time extends the signal transition time accordingly.  
If this parameter has the value 0, no debouncing takes place. Otherwise, the set value corresponds to the time (in ms) that the input signal must be present and stable.
- Switch-off delay  
This parameter specifies the duration of the switch-off delay (in ms).

### **Configuration of the barcode tape selection and tape value correction**

(*MEASUREMENT DATA* tab, *Barcode tape*)

- Barcode tape with 30 mm grid (BCB G30) or 40 mm grid (BCB G40) \*
- Tape value correction \*\*

### **Configuration of position detection**

(*DATA PROCESSING* tab, *Position > Detection*)

- Integration depth \*
- Scaling free resolution \*
- Preset \*
- Offset \*
- Error handling procedures \*

### **Configuration of position monitoring**

(*DATA PROCESSING* tab, *Position > Monitoring*)

- Position limit value 1/2 \*

### **Configuration of speed detection**

(*DATA PROCESSING* tab, *Speed > Detection*)

- Speed measurement averaging \*
- Scaling free resolution \*
- Error handling procedures \*

### **Configuration of speed monitoring**

(*DATA PROCESSING* tab, *Measurement data > Speed > Monitoring*)

- Speed limit value 1-4 \*

### **Configuration of the measurement value display**

(*DATA PROCESSING* tab, *General preparation*)

- Unit \*
- Count direction \*
- Output mode sign \*

### **Configuration of monitoring of the reading quality**

(*DATA PROCESSING* tab, *Reading quality*)

- Warning threshold for reading quality in %\*\*
- Error threshold for reading quality in % \*\*

### **Configuration of the data output**

(*DATA PROCESSING* tab, *Output, Preparation*)

- Position resolution \*
- Speed resolution \*

### **Configuration of the communication data**

(*COMMUNICATION* tab)

- Configuration of the SERVICE USB interface



*The set PROFIBUS address is not displayed here.*

---

### 9.3.5 *DIAGNOSTICS* function

The *DIAGNOSTICS* function is available in the Process and Service operating modes. The device event log is displayed with the *DIAGNOSTICS* function.




Figure 9.5: *DIAGNOSTICS* webConfig function

### 9.3.6 *MAINTENANCE* function

The *MAINTENANCE* function is only available in the Service operating mode.

Functionalities:

- User management
- Devices Backup/Restore
- Firmware update
- System clock
- Setting of the user interface




Figure 9.6: *MAINTENANCE* webConfig function



## 9.4 The role concept of the webConfig users

This web based graphical operator control program is structured in a way that a logical sequence of operations ensues that follows the required actions and their corresponding roles. This means that any actions that belong to a certain work step or a certain role are situated in close proximity (preferably on the same user interface screen).

### 9.4.1 Roles

The webConfig using concept provides the following roles for the customer:

- "Observer" Display of general information
- "Operator" Operate the sensor
- "Maintenance" Operate and maintain the sensor
- "Planning Engineer" Additional authority, e.g. manage projects

These roles serve the end consumer for facility operation. It admits another 3 additional roles which serves TR-Electronic GmbH for the user support, for the device set up and for test purposes. The permissions of the respective roles shall be considered ascending. An "Observer" has the least permissions, a "Planning Engineer" the most.



#### **Assigning roles as a "Planning Engineer".**

*In order to preserve all access rights to the measurement system, a role "Planning Engineer" must be created before the installation of further roles. As a "Planning Engineer", subordinate roles can be managed.*

---

The following definitions show what constitutes the individual roles and where they are distinguished.

#### 9.4.1.1 The role "Observer"

The "Observer" takes a purely passive role. The Observer can see only the general device data, which are offered on the initial page and does not need password for the logon, since it does not have any further authorities. An Observer also can be described as a "Guest".

Allowed actions:

- View general/public data:
  - Start page
  - Type plate
  - Hardware and software version numbers
  - Installation descriptions
  - Technical specification
- Login

An "Observer" cannot change any device parameters and cannot switch the device to another operating state ("Process" or "Service" mode).

### 9.4.1.2 The role “Operator”

The "Operator" is strictly an operator of the sensor who accompanies and observes production operation ("Process" mode). He is also an observer. He can read the parameters for production operation but cannot change them.

Allowed actions:

- *Allowed actions of the role "Observer"*
- Perform adjustment actions in the "Setup" tab without changing the devices' parameter settings
- Switch the operating state ("Process" mode, "Service" mode)
- Restart the device ("Reset")
- View selected device parameters
- View selected production parameters
- Observe the current production progress (current result, production statistics, error messages)
- Call diagnosis functions of a basically reading type:
  - Read event protocol
  - Confirm event protocol
  - Read statistical information
  - Read firmware information

### 9.4.1.3 The role “Maintenance”

A "Maintenance" employee is an operator who can influence production operation within defined limits (set threshold values) and call up diagnostic functions.

The "maintenance" employee can perform all tasks of the "operator" role, as well as the following additional tasks:

Allowed actions:

- *Allowed actions of the role "Operator"*
- Additional switching of the operating state ("Standby" mode, "Host In"/"Host Out" switches)
- Carry out teach functions for device parameterization
- Change selected device parameters
- Change I/O parameters (Digital I/O and communication parameters)
- Reset of process related statistic data
- Clear the event protocol

### 9.4.1.4 The role “Planning Engineer”

A “Planning Engineer” (or “specialist”/supervisor”) manages the conduct of production beyond the role of maintenance by creating profiles/projects, managing check programs and changing their sequence. He can change I/O parameters, update the firmware and manage users (roles).

Allowed actions:

- *Allowed actions of the role "Maintenance"*
- Reset the device to factory settings
- Create/delete check programs (control flow oriented sensor)
- Edit the program sequence (create, delete or change tools, control flow oriented sensor)
- Manage user data (create, delete or change users)
- Define startup role (observer, operator, maintenance or planning engineer)
- Reset selected statistical data (customer)
- Update firmware (customer)

## 10 Diagnostics and troubleshooting

### 10.1 What to do in case of failure?

After switching on the BE 901 PB, display elements (see chapter 3.3) assist in checking the proper function and troubleshooting.

In case of error, you can determine the error from the LED displays. With the error message you can determine the cause of the error and initiate measures to rectify it.

- ✎ Switch off the system and leave it switched off.
- ✎ Analyze the cause of the error using the operation indicators, the error messages and the diagnostic tools (also with the help of the webConfig tool, *DIAGNOSTICS* tab) and rectify the error.

#### NOTICE

**Contact TR-Electronic GmbH.**

✎ If you are unable to rectify a fault, contact the TR-Electronic GmbH.

#### 10.1.1 Diagnostics with webConfig tool

System events are displayed in the webConfig tool via the *DIAGNOSTICS* tab. Noteworthy system events are recorded in the event log. Depending on their importance, the events are classified as info, warning, error and critical error.

The statistics counters detect the number of all recorded as well as non-acknowledged messages. With the message filters, the events can be filtered according to their status and their class.




Figure 10.1: *DIAGNOSTICS* webConfig function

## 10.2 Operating indicators of the LEDs

You can ascertain general causes of errors via the PWR and BUS status LEDs (see Table 10.4).

Table 10.1: PWR LED displays – causes and measures

Faults	Possible cause	Measures
Off	<ul style="list-style-type: none"> <li>- No supply voltage connected to the device</li> <li>- Hardware error</li> </ul>	<ul style="list-style-type: none"> <li>- Check supply voltage</li> <li>- Contact TR-Electronic GmbH</li> </ul>
Green, flashing	<ul style="list-style-type: none"> <li>- Device is being initialised</li> </ul>	
Red, flashing	<ul style="list-style-type: none"> <li>- No barcode in the scanning beam</li> <li>- No valid measurement value</li> </ul>	<ul style="list-style-type: none"> <li>- Query BCB diagnostic data and carry out the resulting (see chapter 10.4 “Checklist for causes of errors”, Table 10.5: Position measurement errors – causes and measures)</li> </ul>
Red, continuous light	<ul style="list-style-type: none"> <li>- Error</li> <li>- Device function is limited</li> <li>- Internal device error</li> </ul>	<ul style="list-style-type: none"> <li>- Determine the cause of the device error using the event log of the webConfig diagnostics</li> <li>- Contact TR-Electronic GmbH</li> </ul>
Orange, continuous light	<ul style="list-style-type: none"> <li>- Device in <i>Service</i> mode</li> </ul>	<ul style="list-style-type: none"> <li>- Reset the device to <i>Process</i> mode using the webConfig tool</li> </ul>

## 10.3 Error messages on the display

Via the optional display of the BE 901 PB, the device outputs the following possible error status information while it has the *BE901 Info* device status:

- **System OK:** BE 901 PB operating error-free.
- **Warning:** Warning message. Query device status using PROFIBUS module 6.
- **Error:** Device function is not ensured.




Figure 10.2: Example: Device status/error status information on the display

## 10.4 Checklist for causes of errors

Table 10.2: Service interface errors – causes and measures

Faults	Possible cause	Measures
webConfig does not start	<ul style="list-style-type: none"> <li>- Incorrectly connected interconnection cable</li> <li>- Connected BE 901 PB is not recognized</li> <li>- No communication via USB service interface</li> <li>- Old webConfig configuration in the browser cache</li> </ul>	<ul style="list-style-type: none"> <li>- Check interconnection cable</li> <li>- Install USB driver</li> <li>- Clear browser history</li> </ul>

Table 10.3: Process interface errors – causes and measures

Faults	Possible cause	Measures
Sporadic network errors	- Check wiring for proper contacting	Check wiring: <ul style="list-style-type: none"> <li>- Check wire shielding</li> <li>- Check wires used</li> </ul>
	- EMC coupling	<ul style="list-style-type: none"> <li>- Observe contact quality of screwed or soldered contacts in the wiring</li> <li>- Avoid EMC coupling caused by power cables laid parallel to device lines</li> <li>- Separate laying of power and data communications cables</li> </ul>
	- Network expansion exceeded	- Check max. network expansion as a function of the max. cable lengths

Table 10.4: LED indicators - interface errors – causes and measures

Faults	Possible cause	Measures
BUS LED "Off"	- No supply voltage connected to the device	- Check supply voltage
	- Device not yet recognized by the PROFIBUS	- Check device address
	- Hardware error	- Contact TR-Electronic GmbH
BUS LED "red flashing"	- Incorrect wiring	- Check wiring
	- Communication error: Configuration failed	- Check configuration, in particular with respect to address assignment
	- Master: no data exchange	- Carry out a reset on the control
	- Communication error on the PROFIBUS: No communication established to master	<ul style="list-style-type: none"> <li>- Check protocol settings</li> <li>- Check configuration, in particular with respect to address assignment</li> </ul>
	- Wrong device address set	- Check configuration, in particular with respect to address assignment
	- Incorrect configuration	- Check configuration, in particular with respect to address assignment
	- Different protocol settings	- Check protocol settings

**Table 10.5: Position measurement errors – causes and measures**

<b>Faults</b>	<b>Possible cause</b>	<b>Measures</b>
Measurement value or reading quality is continuously instable	<ul style="list-style-type: none"><li>- Soiling of the BE 901 PB optics</li></ul>	<ul style="list-style-type: none"><li>- Clean the optics of the BE 901 PB</li></ul>
Measurement value or reading quality is poor <ul style="list-style-type: none"><li>- at certain position values</li><li>- always at the same position values</li></ul>	<ul style="list-style-type: none"><li>- Soiling of the barcode tape</li></ul>	<ul style="list-style-type: none"><li>- Clean the barcode tape</li><li>- Replace the barcode tape</li></ul>
No measurement value can be determined	<ul style="list-style-type: none"><li>- No code in scanning beam</li><li>- Code not in the working range of the BE 901 PB</li></ul>	<ul style="list-style-type: none"><li>- Align the scanning beam with the barcode tape</li><li>- Align the BE 901 PB with the barcode tape (working range 50 mm ... 170 mm)</li></ul>
Faulty measurement value	<ul style="list-style-type: none"><li>- Wrong barcode tape</li><li>- BCB grid different from BE901 configuration</li><li>- Preset or offset active</li><li>- Wrong unit of measurement or resolution configured</li></ul>	<ul style="list-style-type: none"><li>- Change BE901 configuration to the barcode tape that is being used</li></ul>

## 11 Care, maintenance and disposal

### 11.1 Cleaning

If there is dust on the BE 901 PB device:

- ✎ Clean the BE 901 PB device with a soft cloth; use a cleaning agent (commercially available glass cleaner) if necessary.

#### **NOTICE**

**Do not use aggressive cleaning agents!**

- ✎ Do not use aggressive cleaning agents such as thinner or acetone for cleaning the BE 901 PB device.

### 11.2 Servicing

The BE 901 PB does not normally require any maintenance by the operator. Repairs to the device must only be carried out by the manufacturer.

- ✎ For repairs, contact TR-Electronic GmbH.

#### 11.2.1 Firmware update

A firmware update can only be performed by TR-Electronic GmbH.

- ✎ For firmware updates, contact TR-Electronic GmbH.

#### 11.2.2 BCB repair with repair kit

If the barcode tape has been damaged, e.g. by falling parts, you can download a repair kit for the BCB.

#### **NOTICE**

**Do not use the BCB repair kit on a permanent basis!**

- ✎ Use the barcode tape created with the repair kit only temporarily as an emergency solution.

*The optical and mechanical properties of the self-printed barcode tape do not correspond to those of the original barcode tape.*

*Self-printed barcode tape should not remain in the system on a permanent basis.*

- ✎ Original repair tapes can be ordered on request from TR-Electronic GmbH.

#### Repair kit download:

**BCB G30:** [www.tr-electronic.com/f/zip/TR-E-TI-MUL-0109](http://www.tr-electronic.com/f/zip/TR-E-TI-MUL-0109)

0.9 m of barcode tape is provided on each A4 sheet.

Five lines of 18 cm with six code-information segments of 30 mm each

Tape lengths: 0 ... 9999.99 m in different files per 500 m

**BCB G40:** [www.tr-electronic.com/f/zip/TR-E-TI-MUL-0110](http://www.tr-electronic.com/f/zip/TR-E-TI-MUL-0110)

1 m of barcode tape is provided on each A4 sheet.

Five lines of 20 cm with five code-information sections of 40 mm each

Tape lengths: 0 ... 9999.99 m in different files per 500 m

### Replacing a section of defective barcode tape:

- ✚ Determine the coding of the defective area.
- ✚ Print out the coding for the given area.
- ✚ Affix the printed code over the defective section of barcode tape.

#### **NOTICE**

#### **Printing coding**

- ✚ *Select only those pages that are actually required.*
- ✚ *Change the printer settings so that the barcode is not distorted.*
- ✚ *Check the print results and measure the distance between two barcodes:*
  - *BCB G40: 40 mm (see Figure 11.1)*
  - *BCB G30: 30 mm (see Figure 11.2)*
- ✚ *Cut the code strips and arrange them next to one another. The code content must always increase or decrease in increments of 30 mm or 40 mm.*

*Check that the printed values increase by 3 or 4.*



Figure 11.1: Checking the print results of the BCB G40 repair kit (40 mm grid)



Figure 11.2: Checking the print results of the BCB G30 repair kit (30 mm grid)

## 11.3 Disposing

- ✚ For disposal observe the applicable national regulations regarding electronic components.




## 12 Technical data

### 12.1 General specifications

Table 12.1: Optics

Light source	Laser diode
Wavelength	655 nm
Pulse duration	< 150 µs
Max. output power	1.8 mW
Life expectancy laser diode	100,000 h (typ. at +25 °C)
Beam deflection	Via rotating polygon wheel
Exit window	Glass
Laser class	1 according to IEC/EN 60825-1:2014
Working range	50 mm ... 170 mm At a reading distance of 50 mm, the reading field width is 120 mm. At a reading distance beyond 100 mm, the reading field width is 160 mm (see Figure 12.1: BE 901 PB reading field curve).



- 1: Reading field width [mm]
- 2: Reading distance [mm]

Figure 12.1: BE 901 PB reading field curve

**Table 12.2: Measurement data**

Reproducibility (1 sigma)	± 0.05 mm
Output time	1 ms ... 30 ms (configurable), default: 1 ms
Response time	8 ms factory setting (adjustable)
Basis for contouring error calculation	4 ms
Measurement range	0 ... 10,000,000 mm
Resolution	0.1 mm factory setting (adjustable)
Max. traverse rate	10 m/s

**Table 12.3: Operating and display elements**

Display	Monochromatic graphical display, 128 x 32 pixels, With background lighting
Keyboard	Two buttons
LEDs	Two LEDs for power (PWR) and bus state (BUS), two-colored (red/green)

**Table 12.4: Mechanical data**

Housing	Diecast aluminum
Connection technology	- BE 901 PB with BE 901 MS PB: M12 connectors - BE 901 PB with BE 901 MK PB: Terminal blocks with spring cage terminals (5-pin)
Degree of protection	IP 65
Weight	Approx. 580 g (without connection hood)
Dimensions (without connection hood)	(H x W x D) 108.7 mm x 100.0 mm x 48.3 mm
Dimensions (with BE 901 MS PB connection hood)	(H x W x D) 108.7 mm x 100.0 mm x 48.3 mm
Dimensions (with BE 901 MK PB connection hood)	(H x W x D) 147.4 mm x 100.0 mm x 48.3 mm
Dimensions of BE 901 MS PB connection hood	(H x W x D) 64.0 mm x 43.5 mm x 33.5 mm
Dimensions of BE 901 MK PB connection hood	(H x W x D) 64.0 mm x 43.5 mm x 83.5 mm

**Table 12.5: Environmental data**

Air humidity	Max. 90% rel. humidity, non-condensing
Vibration	IEC 60068-2-6, test Fc
Shock / Continuous shock	IEC 60068-2-27, test Ea
Electromagnetic compatibility	IEC 61000-6-3 IEC 61000-6-2 (contains IEC 61000-4-2, -3, -4, -5, -6)

**Table 12.6: Product Reliability**

MTTF	83 years *
MTTF <sub>d</sub>	166 years *

\* at 25 °C ambient temperature

**Table 12.7: Certifications, conformity**

Conformity	CE, CDRH
Certifications	UL 60950-1, CSA C 22.2 No. 60950-1

### ⚠ CAUTION

#### **UL applications!**

*For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).*

## 12.1.1 BE 901 PB without heating

### ⚠ CAUTION

#### **UL applications!**

*For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).*

**Table 12.8: Electrical equipment**

Interface type	PROFIBUS DP-V0 acc. to IEC 61158, automatic baud rate detection up to 12 Mbit/s
Service USB interface	Mini-B type USB 2.0 socket
Switching input / Switching output	Two switching inputs/ outputs Functions are freely programmable via PROFIBUS interface Switching input: 18 ... 30 VDC, depending on supply voltage, I max. = 8 mA Switching output: 18 ... 30 VDC, depending on supply voltage, I max. = 60 mA (short-circuit proof) Switching inputs/outputs protected against polarity reversal!
PWR LED green	Device ready (power on)
Operating voltage U <sub>B</sub>	18 ... 30 VDC (Class 2, safety class III)
Power consumption	max. 3.7 W

**Table 12.9: Ambient temperature**

Ambient temperature (operation)	-5 °C ... +50 °C
Ambient temperature (storage)	-35 °C ... +70 °C

## 12.1.2 BE 901 PB with heating

### **⚠ CAUTION**

#### **UL applications!**

*For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).*

**Table 12.10: Electrical equipment**

Operating voltage $U_B$	18 ... 30 VDC
Power consumption	Max. 17.7 W
Structure of the heating	Housing heating and separate heating of the optics glass
Warmup time	Minimum 30 min at +24 VDC and an ambient temperature of -35 °C
Minimum conductor cross section	Conductor cross section of at least 0.75 mm <sup>2</sup> for the supply voltage supply line. <b>Note:</b> Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 ready-made cable not usable (insufficient conductor cross section).

**Table 12.11: Ambient temperature**

Ambient temperature (operation)	-35 °C ... +50 °C
Ambient temperature (storage)	-35 °C ... +70 °C

## 12.2 Barcode tape

**Table 12.12: BCB dimensions**

	<b>BCB G40</b>	<b>BCB G30</b>
Grid	40 mm	30 mm
Standard height	47 mm, 25 mm	47 mm, 25 mm
Length	0 ... 5 m, 0 ... 10 m, 0 ... 20 m, ..., 0 ... 150 m, 0 ... 200 m; Special lengths and special coding (see chapter 13.6)	0 ... 5 m, 0 ... 10 m, 0 ... 20 m, ..., 0 ... 150 m; Special lengths and special coding (see chapter 13.6)
Tape tolerance	± 1 mm per meter	± 1 mm per meter

### **NOTICE**

#### **Twin tapes on request**

👉 *Twin tapes can be ordered on request (see chapter 13.6 "Barcode tapes").*


**Table 12.13: BCB structure**

Manufacturing process	Filmsetting
Surface protection	Polyester, matt
Base material	Polyester film, affixed without silicone
Adhesive	Acrylate adhesive
Strength of adhesive	0.1 mm
Adhesive strength (average values)	On aluminum: 25 N/25 mm On steel: 25 N/25 mm On polycarbonate: 22 N/25 mm On polypropylene: 20 N/25 mm

**Table 12.14: BCB structure**

Recommended processing temperature	0 °C ... +45 °C
Ambient temperature	-40 °C ... +120 °C
Dimensional stability	No shrinkage, tested according to DIN 30646
Curing	Final curing after 72 h; the BE 901 PB can detect the position immediately after the BCB is affixed.
Tear resistance	150 N
Elongation at tear	Min. 80%, tested in accordance with DIN 50014, DIN 51220
Weathering resistance	UV-light, humidity, salt spray (150 h/5 %)
Chemical resistance (checked at 23 °C over 24 h)	Transformer oil, diesel oil, white spirit, heptane, ethylene glycol (1:1)
Behavior in fire	Self-extinguishing after 15 s, does not drip
Surface	Grease-free, dry, clean, smooth
Mechanical properties	Scratch and wipe resistant, UV resistant, moisture resistant, partly chemical resistant

## 12.3 Dimension drawings



- 1: Reference point for the barcode position
- 2: Optical axis

Figure 12.2: Dimension drawing BE 901 PB without connection hood (all dimensions in mm)




Figure 12.3: Dimension drawing BE 901 PB with BE 901 MS PB connection hood (all dimensions in mm)




Figure 12.4: Dimension drawing BE 901 PB with BE 901 MK PB connection hood (all dimensions in mm)

## 12.4 : Accessories dimension drawings




Figure 12.5: Dimension drawing BE 901 MS PB connection hood (all dimensions in mm)




Figure 12.6: Dimension drawing BE 901 MK PB connection hood (all dimensions in mm)






Figure 12.7: Dimension drawing BE 901 FA-001 mounting device (all dimensions in mm)





Figure 12.8: Dimension drawing BE 901 FA-002 mounting device (all dimensions in mm)



- 1: Clamping jaws for mounting on the BE 901 PB
- 2: Clamp profile for fastening to round or oval pipes ( $\varnothing$  16 ... 20 mm)
- 3: Rod holder, turnable 360 °

Figure 12.9: Dimension drawing BE 90 FA-001 mounting device (all dimensions in mm)




Figure 12.10: Dimension drawing BE 901 FA-003 mounting device (all dimensions in mm)

## 12.5 Barcode tape dimension drawings



Figure 12.11: Dimension drawing barcode tape BCB G40 with 40 mm grid (all dimensions in mm)



Figure 12.12: Dimension drawing barcode tape BCB G30 with 30 mm grid (all dimensions in mm)

## 13 Ordering information and accessories

### 13.1 BE 901 PB type overview

Table 13.1: BE 901 PB type overview

Art.-No.	Part designation	Description
40804-12000	BE 901 PB	BE 901 PB with PROFIBUS DP interface
40804-12002	BE 901 PB D	BE 901 PB with PROFIBUS DP interface and display
40804-12001	BE 901 PB D H	BE 901 PB with PROFIBUS DP interface, display and heating

### 13.2 Connection hoods

Table 13.2: BE 901 PB connection hoods

Art.-No.	Part designation	Description
40804-22001	BE 901 MS PB	Connection hood with M12 connectors
40804-22002	BE 901 MK PB	Connection hood with spring-cage terminals

### 13.3 Terminating resistor

Table 13.3: Accessory – Terminating resistor

Art.-No.	Part designation	Description
40803-40005	BE90-CO-TE-5P	M12-connector, 4 pin B-coded with integrated terminating resistor for BUS OUT (termination)

### 13.4 Other accessories

Table 13.4: Accessories – BE 901 PB connectors

Art.-No.	Part designation	Description
40803-40003	BE90-CO-MA-5P	M12 axial plug, 5 pin B-coded, PG9, shielded, for signal line BUS OUT
40803-40004	BE90-CO-FE-5P	M12 axial socket, 5 pin B-coded, PG9, shielded, for signal line HOST or BUS IN
40803-40006	BE90-CO-PI-5P	M12 axial socket, 5 pin A-coded, PG9, for supply voltage

Table 13.5: Accessory – USB cable

Art.-No.	Part designation	Description
64070120	USB-A to USB-miniB cable	USB service cable, 1 Type A and Mini-B type connector, length 3 m

## 13.5 Mounting device

Table 13.6: Accessories – Mounting device

Art.-No.	Part designation	Description
40803-50001	BE 90 FA-001	Mounting device for rod
40804-50001	BE 901 FA-001 (BE901 Befestigung)	Mounting device for wall mounting - precise alignment of the BE 901 PB without adjustment
40804-50002	BE 901 FA-002 (BE901 Befestigungswinkel)	Mounting bracket for wall mounting
40804-50003	BE 901 FA-003 (BE901 Befestigung kompl.)	Mounting bracket for rod

## 13.6 Barcode tapes

Table 13.7: Accessories – BCB G40-Barcode tapes with 40 mm grid

Art.-No.	Part designation	Description
40803-60000	BCB-005	Barcode tape 5 m length, 47 mm height
40803-60001	BCB-010	Barcode tape 10 m length, 47 mm height
40803-60002	BCB-020	Barcode tape 20 m length, 47 mm height
40803-60003	BCB-030	Barcode tape 30 m length, 47 mm height
40803-60004	BCB-040	Barcode tape 40 m length, 47 mm height
40803-60005	BCB-050	Barcode tape 50 m length, 47 mm height
40803-60006	BCB-060	Barcode tape 60 m length, 47 mm height
40803-60007	BCB-070	Barcode tape 70 m length, 47 mm height
40803-60008	BCB-080	Barcode tape 80 m length, 47 mm height
40803-60009	BCB-090	Barcode tape 90 m length, 47 mm height
40803-60010	BCB-100	Barcode tape 100 m length, 47 mm height
40803-60011	BCB-110	Barcode tape 110 m length, 47 mm height
40803-60012	BCB-120	Barcode tape 120 m length, 47 mm height
40803-60013	BCB-130	Barcode tape 130 m length, 47 mm height
40803-60015	BCB-150	Barcode tape 150 m length, 47 mm height
40803-60018	BCB-180	Barcode tape 180 m length, 47 mm height
40803-60020	BCB-200	Barcode tape 200 m length, 47 mm height
40803-60023	BCB-230	Barcode tape 230 m length, 47 mm height
40803-60025	BCB-250	Barcode tape 250 m length, 47 mm height
40803-60026	BCB-260	Barcode tape 260 m length, 47 mm height
40803-60027	BCB-270	Barcode tape 270 m length, 47 mm height
40803-60028	BCB-280	Barcode tape 280 m length, 47 mm height
40803-69001	MVS label 40 mm 10 pieces	MVS label, 40 mm grid; packaging unit: 10 pieces
40803-69002	MVO label 40 mm 10 pieces	MVO label, 40 mm grid; packaging unit: 10 pieces

...

...

on request	BCB G40 special length 47 mm height	Barcode tape with special length, 47 mm high
on request	BCB G40 special length 25 mm height	Barcode tape with special length, 25 mm high
on request	BCB G40 special length / height	Barcode tape with special length and height
on request	BCB G40 special length / height / winding	Barcode tape with special length, height and wrapping direction

**Table 13.8: Accessories – BCB G30-Barcode tapes with 30 mm grid**

Art.-No.	Part designation	Description
40803-80001	BCB G30-010	Barcode tape, 10 m length, 47 mm high
40803-80005	BCB G30-050	Barcode tape, 50 m length, 47 mm high
on request	MVS label 30 mm 10 pieces	MVS label, 30 mm grid; packaging unit: 10 pieces
on request	MVO label 30 mm 10 pieces	MVO label, 30 mm grid; packaging unit: 10 pieces
on request	BCB G30 special length 47 mm height	Barcode tape with special length, 47 mm high
on request	BCB G30 special length 25 mm height	Barcode tape with special length, 25 mm high
on request	BCB G30 special length / height	Barcode tape with special length and height

**Table 13.9: Accessories – Twin tapes**

Art.-No.	Part designation	Description
on request	BCB G40 twin tape special length / height	BCB G40 twin tape, 40 mm grid, with special length and high; delivery contents: Two barcode tapes with the same value range
on request	BCB G30 twin tape special length / height	BCB G30 twin tape, 30 mm grid, with special length and high; delivery contents: Two barcode tapes with the same value range
on request	BCB G40 twin tape special length	BCB G40 twin tape, 40 mm grid, 47 mm high; delivery contents: Two barcode tapes with the same value range
on request	BCB G30 twin tape special length	BCB G30 twin tape, 30 mm grid, 47 mm high; delivery contents: Two barcode tapes with the same value range

## 14 EC Declaration of Conformity

The barcode positioning systems of the BE 901 PB series have been developed and manufactured in accordance with the applicable European standards and directives.

The manufacturer of the product, TR-Electronic GmbH in D-78647 Trossingen, possesses a certified quality assurance system in accordance with ISO 9001.



Download EU Declaration of Conformity: [www.tr-electronic.com/f/TR-E-KE-DGB-0026](http://www.tr-electronic.com/f/TR-E-KE-DGB-0026)

## 15 Appendix

### 15.1 Barcode sample

#### 15.1.1 BCB G40 barcode tape with 40 mm grid



Figure 15.1: Continuous, 40 mm grid




Figure 15.2: Single label MVS, 40 mm grid




Figure 15.3: Single label MV0, 40 mm grid




Figure 15.4: Single marker label, 40 mm grid



### 15.1.2 BCB G30 barcode tape with 30 mm grid



Figure 15.5: Continuous, 30 mm grid




Figure 15.6: Single label MVS, 30 mm grid




Figure 15.7: Single label MV0, 30 mm grid




Figure 15.8: Single marker label, 30 mm grid